JVC

Dear Customer,

Thank you for purchasing this digital video camera. Before use, please read the safety information and precautions contained in the pages 2 – 3 to ensure safe use of this product.

ENGLISH

DIGITAL VIDEO CAMERA


GR-D93 GR-D73 GR-D33

Please visit our Homepage on the World Wide Web for Digital Video Camera:

http://www.jvc.co.jp/english/cyber/

For Accessories:

http://www.jvc.co.jp/english/accessory/



The camcorder illustrations appearing in this instruction manual are of the GR-D93.

The D.S.C. (Digital Still Camera) features are available on GR-D93 and GR-D73.

INSTRUCTIONS

GETTING STARTED 5

VIDEO RECORDING & PLAYBACK **11**

DIGITAL STILL CAMERA (D.S.C.) RECORDING & PLAYBACK (GR-D93/D73 only) 18

ADVANCED FEATURES 25

REFERENCES 38

TERMS 54

For Customer Use:

Enter below the Model No. and Serial No. which is located on the bottom of the camcorder. Retain this information for future reference.

Model No.

....

Serial No.

To deactivate the demonstration, set "DEMO MODE" to "OFF". (pr pg. 25, 27)



SAFETY PRECAUTIONS



CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK,
DO NOT REMOVE COVER (OR BACK).
NO USER-SERVICEABLE PARTS INSIDE.
REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

WARNING: TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS UNIT TO RAIN OR MOISTURE.

NOTES:

- The rating plate (serial number plate) and safety caution are on the bottom and/or the back of the main unit.
- The rating information and safty caution of the AC Adapter are on its upper and lower sides.

CAUTIONS:

- This camcorder is designed to be used with NTSC-type color television signals. It cannot be used for playback with a television of a different standard. However, live recording and LCD monitor/viewfinder playback are possible anywhere.
- Use the JVC BN-V408U/V416U/V428U battery packs and, to recharge them or supply power to the camcorder from an AC outlet, use the provided multi-voltage AC Adapter. (An appropriate conversion adapter may be necessary to accommodate different designs of AC outlets in different countries.)

Caution on Replaceable lithium battery

The battery used in this device may present a fire or chemical burn hazard if mistreated.

Do not recharge, disassemble, heat above 100°C (212°F) or incinerate

Replace battery with Panasonic (Matsushita Electric), Sanyo, Sony or Maxell CR2025.

Danger of explosion or Risk of fire if the battery is incorrectly replaced.

- · Dispose of used battery promptly.
- Keep away from children.
- Do not disassemble and do not dispose of in fire.

This product has a fluorescent lamp that contains a small amount of mercury. Disposal of these materials may be regulated in your community due to environmental considerations.

For disposal or recycling information please contact your local authorities, or the Electronics Industries Alliance:

http://www.eiae.org

When the equipment is installed in a cabinet or on a shelf, make sure that it has sufficient space on all sides to allow for ventilation (10 cm (3-15/16") or more on both sides, on top and at the rear).

Do not block the ventilation holes.

(If the ventilation holes are blocked by a newspaper, or cloth etc. the heat may not be able to get out.)

No naked flame sources, such as lighted candles, should be placed on the apparatus.

When discarding batteries, environmental problems must be considered and the local rules or laws governing the disposal of these batteries must be followed strictly.

The apparatus shall not be exposed to dripping or splashing.

Do not use this equipment in a bathroom or places with water.

Also do not place any containers filled with water or liquids (such as cosmetics or medicines, flower vases, potted plants, cups etc.) on top of this unit.

(If water or liquid is allowed to enter this equipment, fire or electric shock may be caused.)

Do not point the lens or the viewfinder directly into the sun. This can cause eye injuries, as well as lead to the malfunctioning of internal circuitry. There is also a risk of fire or electric shock.

CAUTION!

The following notes concern possible physical damage to the camcorder and to the user.

When carrying, be sure to always securely attach and use the provided strap. Carrying or holding the camcorder by the viewfinder and/or the LCD monitor can result in dropping the unit. or in a malfunction.

Take care not to get your finger caught in the cassette holder cover. Do not let children operate the camcorder, as they are particularly susceptible to this type of injury.

Do not use a tripod on unsteady or unlevel surfaces. It could tip over, causing serious damage to the camcorder.

CAUTION!

Connecting cables (Audio/Video, S-Video, etc.) to the camcorder and leaving it on top of the TV is not recommended, as tripping on the cables will cause the camcorder to fall, resulting in damage.

IMPORTANT SAFTY INSTRUCTIONS

- 1. Read these instructions.
- 2. Keep these instructions.
- 3. Heed all warnings.
- 4. Follow all instructions.
- 5. Do not use this apparatus near water.
- 6. Clean only with dry cloth.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Only use attachments/accessories specified by the manufacturer.
- 10. Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.



- Unplug this apparatus during lightning storms or when unused for long periods of time.
- 12. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.



This camcorder is designed exclusively for the digital video cassette, SD Memory Card and MultiMediaCard. Only cassettes marked "Mim DY" and memory cards* marked "Sim" or "MultiWediaCard" can be used with this unit.


Before recording an important scene...

- ...make sure you only use cassettes with the Mini DV mark $\mathbf{M}^{\text{Mini}}\mathbf{D}^{\mathbf{V}}$.
- ...make sure you only use memory cards* with the mark or *MultiMediaCard* .
- ...remember that this camcorder is not compatible with other digital video formats.
- ...remember that this camcorder is intended for private consumer use only. Any commercial use without proper permission is prohibited. (Even if you record an event such as a show, performance or exhibition for personal enjoyment, it is strongly recommended that you obtain permission beforehand.)
- Memory cards can be used with GR-D93 and GR-D73 only.

GETTING STARTED	5	ADVANCED FEATURES	25
Provided Accessories	5	MENUS FOR DETAILED ADJUSTMENT	25
Power	6	Changing The Menu Settings	
Grip Adjustment	7	Recording Menus	
Operation Mode		Playback Menus	28
Date/Time Settings	8	FEATURES FOR RECORDING	29
Viewfinder Adjustment		White LED Light	
Brightness Adjustment Of The Display	9	Night Alive	
Tripod Mounting	9	Wipe Or Fader Effects	30
Loading/Unloading A Cassette		Program AE With Special Effects	
Loading/Unloading A Memory Card (GR-D93/73 only)	10	Snapshot (For Video Recording)	
VIDEO DECORDINO O DI AVDACIV		Auto Focus	
VIDEO RECORDING & PLAYBACK	11	Manual Focus	32
VIDEO DECORDING	- 11	Exposure Control	32
VIDEO RECORDING		Iris Lock	32
Basic Recording		Backlight Compensation	33
LCD Monitor And Viewfinder		White Balance Adjustment	33
Tape Remaining Time		Manual White Balance Adjustment	33
Zooming		EDITING	34
Journalistic Shooting		Dubbing To Or From A VCR	
Self Recording Time Code		Dubbing To A Video Unit Equipped With A DV (Connector
Recording From The Middle Of A Tape		(Digital Dubbing)	
		Connection To A Personal Computer	
VIDEO PLAYBACK		Audio Dubbing (GR-D93/73 only)	37
Normal Playback		Insert Editing (GR-D93/73 only)	37
Still Playback			
Shuttle Search Blank Search		REFERENCES	38
Playback Using The Remote Control (GR-D93/73 only)			
Connections To A TV Or VCR		ADDITIONAL INFORMATION	
Connections to A TV Or VCh	17	TROUBLESHOOTING	
DIGITAL STILL CAMERA (D.S.C.) RECORDING &		CAUTIONS	
	10	USER MAINTENANCE	48
PLAYBACK (GR-D93/D73 only)	18	SPECIFICATIONS	49
D.S.C. RECORDING (GR-D93/D73 only)	12	INDEX	50
Basic Shooting (D.S.C. Snapshot)	18		
Dubbing Still Images Recorded On A Tape To A Mem	norv	TERMS	54
Card			
D.S.C. PLAYBACK (GR-D93/D73 only)			
Normal Playback Of Images			
Auto Playback Of Images			
Index Playback Of Files			
Viewing File Information			
Removing On-Screen Display			
ADDITIONAL FEATURES FOR D.S.C. (GR-D93/D73 only)	22		
Protecting Files			
Deleting Files			
Setting Print Information (DPOF Setting)			

Resetting The File Name24 Initializing A Memory Card24

Provided Accessories



- 1 AC Adapter AP-V14U or AP-V15U
- ② Battery Pack BN-V408U-B
- 3 Audio/Video Cable (ø3.5 mini-plug to RCA plug)
- 4 Core Filter (for USB Cable (provided with GR-D93/73 only) and optional S-Video Cable. pg. 6 for attachment)
- 5 Shoulder Strap (See the right column for attachment)
- 6 CD-ROM
- Memory Card 8 MB (GR-D93/73 only) (Already inserted in the camcorder)
- 8 Remote Control Unit RM-V718U (GR-D93/73 only)
- Lithium Battery CR2025* (GR-D93/73 only) (for remote control unit)
- 10 USB Cable (GR-D93/73 only)
- ① Lens Cap (See the right column for attachment)
- * A lithium battery is pre-installed in the Remote Control Unit at time of shipment (with insulation sheet). To use the Remote Control Unit. remove the insulation sheet.

NOTES:


- In order to maintain optimum performance of the camcorder, provided cables may be equipped with one or more core filter. If a cable has only one core filter, the end that is closest to the filter should be connected to the camcorder.
- Make sure to use the provided cables for connections. Do not use any other cables.

How To Attach The Lens Cap

To protect the lens, attach the provided lens cap to the camcorder as shown in the illustration.

NOTE:

To confirm the lens cap is on correctly make sure the cap is flush to the camcorder.




Place here during shooting.

How To Attach The Shoulder Strap

Follow the illustration.

- Thread the strap through the eyelet.
- **2** Fold it back and thread it through the strap guide and the buckle.
- To adjust the length of the strap, loosen and then tighten the strap in the buckle.
- 3 Slide the strap guide fully towards the eyelet.




How To Attach The Core Filter (for USB Cable (provided with GR-D93/73 only) and optional S-Video Cable)

Attach the core filters to the cables. The core filter reduces interference.

1 Release the stoppers on both ends of the core filter.



- **2** Run the cable through the core filter, leaving approx. 3 cm of cable between the cable plug and the core filter. Wind the cable once around the outside of the core filter as shown in the illustration.
- Wind the cable so that it is not slack.




3 Close the core filter until it clicks shut.



NOTES:

- Take care not to damage the cable.
- When connecting a cable, attach the end with the core filter to the camcorder.

Power



This camcorder's 2-way power supply system lets you choose the most appropriate source of power. Do not use provided power supply units with other equipment.

Charging The Battery Pack

- **1** With the arrow on the battery pack pointing upward, push the battery pack slightly against the battery pack mount ①.
- 2 Slide up the battery pack until it locks in place 2.
- 3 Set the Power Switch to "OFF (CHARGE)".
- **4** Connect the AC Adapter to the camcorder.
- **5** Plug the AC Adapter into an AC outlet. The **POWER/ CHARGE** lamp on the camcorder blinks to indicate charging has started.
- **6** When the **POWER/CHARGE** lamp goes out, charging is finished. Unplug the AC Adapter from the AC outlet. Disconnect the AC Adapter from the camcorder.

To detach the battery pack

Slide the battery pack down slightly while sliding **BATT. RELEASE** to detach it.

Battery pack	Charging time	
BN-V408U*	Approx. 1 hr. 30 min.	
BN-V416U	Approx. 3 hr.	
BN-V428U	Approx. 5 hr.	

^{*} Provided

- If the protective cap is attached to the battery pack, remove it first.
- During charging, the camcorder cannot be operated.
- Charging is not possible if the wrong type of battery is used.

- When charging the battery pack for the first time or after a long storage period, the POWER/CHARGE lamp may not light. In this case, remove the battery pack from the camcorder, then try charging again.
- If the battery operation time remains extremely short even after having been fully charged, the battery is worn out and needs to be replaced. Please purchase a new one.

Using The Battery Pack

Perform steps 1 - 2 in "Charging The Battery Pack".

Maximum continuous recording time

GR-D73/33

Battery pack	LCD monitor on	Viewfinder on
BN-V408U*	1 hr. 10 min.	1 hr. 40 min.
BN-V416U	2 hr. 20 min.	3 hr. 15 min.
BN-V428U	4 hr. 10 min.	5 hr. 50 min.

• GR-D93

Battery pack	LCD monitor on	Viewfinder on
BN-V408U*	1 hr. 5 min.	1 hr. 35 min.
BN-V416U	2 hr. 15 min.	3 hr. 5 min.
BN-V428U	4 hr.	5 hr. 30 min.

^{*} Provided

NOTES:

- Recording time is reduced significantly under the following conditions:
 - Zoom or Record-Standby mode is engaged repeatedly.
 - The LCD monitor is used repeatedly.
 - The playback mode is engaged repeatedly.
 - The White LED Light is used.
- Before extended use, it is recommended that you prepare enough battery packs to cover 3 times the planned shooting time.

ATTENTION:

Before detaching the power source, make sure that the camcorder's power is turned off. Failure to do so can result in a camcorder malfunction

Using AC Power

Connect the AC Adapter to the camcorder as shown in the illustration on page 6.

NOTES:

- The provided AC Adapter features automatic voltage selection in the AC range from 110 V to 240 V.
- Do not allow the DC terminals of the AC Adapter to come in contact with metals, as this can result in a short circuit and cause malfunction.

About Batteries


DANGER! Do not attempt to take the batteries apart, or expose them to flame or excessive heat, as it may cause a fire or explosion.

WARNING! Do not allow the battery or its terminals to come in contact with metals, as this can result in a short circuit and possibly start a fire.

The Benefits Of Lithium-Ion Batteries

Lithium-ion battery packs are small but have a large power capacity. However, when one is exposed to cold temperatures (below 10°C/50°F), its usage time becomes shorter and it may cease to function. If this happens, place the battery pack in your pocket or other warm, protected place for a short time, then





Lithium-ion is vulnerable in colder temperatures.

re-attach it to the camcorder. As long as the battery pack itself is not cold, it should not affect performance. (If you're using a heating pad, make sure the battery pack does not come in direct contact with it.)

For other notes, pg. 38.


Grip Adjustment

- Adjust the velcro strip.
- **2** Pass your right hand through the loop and grasp the grip.
- **3** Adjust your thumb and fingers through the grip to easily operate the Recording Start/Stop Button, Power Switch and Power Zoom Lever. Be sure to fasten the velcro strip to your preference.



Operation Mode

To turn on the camcorder, set the Power Switch to any operation mode except "OFF (CHARGE)" while pressing down the Lock Button located on the switch.



Choose the appropriate operation mode according to your preference using the Power Switch and **VIDEO/ MEMORY** Switch (GR-D93/73 only).

Power Switch Position

Allows you to record using NO special effects or manual adjustments. Suitable for standard recording. The "\(\mathbb{A}\)" indicator appears on the display.

M (Manual Recording):

Allows you to set various recording functions using the Menus. (pq. 25)

If you want more creative capabilities than Full Auto Recording, try this mode.

There is no indication on the display.

OFF:

Allows you to switch off the camcorder.

PLAY:

- Allows you to play back a recording on the tape.
- Allows you to display a still image stored in the memory card or to transfer a still image stored in the memory card to a PC. (GR-D93/73 only)
- Allows you to set various playback functions using the Menus. (pp pg. 25)

VIDEO/MEMORY Switch Position (GR-D93/73 only)

VIDEO:

Allows you to record on a tape or play back a tape. If "REC SELECT" is set to "

"Diagnostic play back a tape. If "ED /

"Diagnostic play back a tape. If "Diagnostic play back a tape. If "ED /

"Diagnostic play back a tape. If "Diagno

MEMORY:

- Allows you to record in a memory card or access data stored in a memory card.
- When the Power Switch is set to "A" or "M", the currently selected image size appears.

Power-Linked Operation

When the Power Switch is set to "A" or "M", you can also turn on/off the camcorder by opening/closing the LCD monitor or pulling out/pushing in the viewfinder.

INFORMATION:

The following explanations in this manual supposes the use of LCD monitor in your operation. If you want to use the viewfinder, close the LCD monitor and pull out the viewfinder fully.

Date/Time Settings

The date/time is recorded onto the tape at all times, but its display can be turned on or off during playback. (pp. 25, 28)

- 1 Set the Power Switch to "M" while pressing down the Lock Button located on the switch.
- 2 Open the LCD monitor fully. (pg. 12)
- **3** Press the MMENU/VOL. Wheel in. The Menu Screen appears.
- 4 Rotate the MMENU/VOL. Wheel to select "@", and press it. The CAMERA DISPLAY Menu appears.
- 5 Rotate the MMENU/VOL. Wheel to select "CLOCK ADJ.", and press it. The parameter for "Month" is highlighted.
- 6 Rotate the MMENU/VOL. Wheel to input the month, and press it. Repeat to input the day, year, hour and minute.
- **7** Rotate the MMENU/VOL. Wheel to select "thRETURN", and press it twice. The Menu Screen closes.

CAMERA DISPLAY BRIGHT ON SCREEN - LCD/TV DATE/TIME - AUTO TIME CODE - OFF CLOCK ADJ. 5:30 PM




NOTE:

Even if you select "CLOCK ADJ.", if the parameter is not highlighted, the camcorder's internal clock continues to operate. Once you move the highlight bar to the first date/ time parameter (month), the clock stops. When you finish setting the minute and press the MENU/VOL. Wheel in, the date and time begin operation from the date and time you have just set.

Viewfinder Adjustment

- I Set the Power Switch to "A" or "M" while pressing down the Lock Button located on the switch.
- 2 Make sure the LCD monitor is closed and locked. Pull out the viewfinder fully and adjust it manually for best viewability.
- 3 Turn the Diopter Adjustment Control until the indications in the viewfinder are clearly focused.



CAUTION:

When retracting the viewfinder, take care not to pinch your fingers.

Brightness Adjustment Of The Display

■ Set the Power Switch to "M" or "PLAY" while pressing down the Lock Button located on the

2 Open the LCD monitor fully. (c pg. 12)

3 Press the MMENU/VOL. Wheel in. The Menu Screen appears.

4 Rotate the MMENU/VOL. Wheel to select "D", and press it. The CAMERA DISPLAY Menu appears.

5 Rotate the MMENU/VOL.

Wheel to select "BRIGHT", and press it. The Menu Screen closes and the brightness control indicator appears.

6 Rotate the **MMENU/VOL**. Wheel until the appropriate brightness is reached.

7 Press the MMENU/VOL. Wheel in.

• It is also possible to adjust the brightness of the viewfinder by pulling out the viewfinder, setting "PRIORITY" in the SYSTEM Menu to "FINDER" (pg. 25, 27) and adjusting as described above.





Tripod Mounting


To attach the camcorder to a tripod, align the direction stud and screw to the mounting socket and stud hole on the camcorder. Then tighten the screw clockwise.

 Some tripods are not equipped with studs.

CAUTION:


When attaching the camcorder to a tripod, extend its legs to

stabilize the camcorder. It is not advised to use small sized tripods. This may cause damage to the unit by falling over.



Loading/Unloading A Cassette

The camcorder needs to be powered up to load or eject a cassette.



1 Slide and hold **OPEN/EJECT** in the direction of the arrow, then pull the cassette holder cover open until it locks. The cassette holder opens automatically.

- Do not touch internal components.
- **2** Insert or remove a tape and press "PUSH HERE" to close the cassette holder.
- Be sure to press only the section labeled "PUSH HERE" to close the cassette holder; touching other parts may cause your finger to get caught in the cassette holder, resulting in injury or product damage.
- Once the cassette holder is closed, it recedes automatically. Wait until it recedes completely before closing the cassette holder cover.
- When the battery pack's charge is low, you may not be able to close the cassette holder cover. Do not apply force.
 Replace the battery pack with a fully charged one or use AC power before continuing.
- **3** Close the cassette holder cover firmly until it locks into place.

Approximate recording time

	_		
Tape	Recording mode		
Tape	SP	LP	
30 min.	30 min.	45 min.	
60 min.	60 min.	90 min.	
80 min.	80 min.	120 min.	

To switch the recording mode, refer to pages 25 and 26.


To protect valuable recordings

Slide the erase protection tab on the back of the tape in the direction of "SAVE". This prevents the tape from being recorded over. To record on this tape, slide the tab back to "REC" before loading it.

For other notes, pg. 38.

Loading/Unloading A Memory Card (GR-D93/73 only)

The provided memory card is already inserted in the camcorder at the time of purchase.



Write/erase protection tab

- Make sure the camcorder's power is off.
- **2** Open the LCD monitor (pg. 12), then open the card cover (MEMORY CARD).
- **3** To load a memory card, firmly insert it with its clipped edge first.

To unload a memory card, push it once. After the memory card comes out of the camcorder, pull it out.

- Do not touch the terminal on the reverse side of the label.
- 4 Close the card cover.

To protect valuable files (available only for SD Memory Card)

Slide the write/erase protection tab on the side of the memory card in the direction of "LOCK". This prevents the memory card from being recorded over. To record on this memory card, slide the tab back to the position opposite to "LOCK" before loading it.

NOTES:

- Be sure to use only SD Memory Cards marked "See" or MultiMediaCards marked "MultiMediaCard".
- Some brands of memory cards are not compatible with this camcorder. Before purchasing a memory card, consult its manufacturer or dealer.
- Before using a new memory card, it is necessary to FORMAT the card. (□ pg. 24)

ATTENTION:


Do not insert or remove the memory card while the camcorder is turned on, as this may cause the memory card to be corrupted or cause the camcorder to become unable to recognize whether or not the card is installed.


Basic Recording

NOTE:

Before continuing, perform the procedures listed below:

- Power (□ pq. 6)
- Loading A Cassette (□ pg. 10)





- 1 Remove the lens cap.
- 2 Open the LCD monitor fully. (pg. 12)
- **3** Set the **VIDEO/MEMORY** Switch to "VIDEO". (GR-D93/73 only)
- **4** Set the Power Switch to "\(\bar{\Pi}\)" or "\(\bar{\Pi}\)" while pressing down the Lock Button located on the switch.
- The POWER/CHARGE lamp lights and the camcorder enters the Record-Standby mode. "PAUSE" is displayed.
- To record in LP (Long Play) mode, pg. 25, 26.
- **5** To start recording, press the Recording Start/Stop Button. The "♣ REC" appears on the display while recording is in progress.
- **6** To stop recording, press the Recording Start/Stop Button again. The camcorder re-enters the Record-Standby mode.

- The image will not appear simultaneously on the LCD monitor and the viewfinder.
- If the Record-Standby mode continues for 5 minutes, the camcorder's power shuts off automatically. To turn the camcorder on again, push back and pull out the viewfinder again or close and re-open the LCD monitor.
- LCD monitor/viewfinder indications:
- When power is supplied from a battery: the "
 battery indicator is displayed. (
 pg. 43)
- When power is supplied from an AC outlet: the "c____" battery indicator does not appear.
- When a blank portion is left between recorded scenes on the tape, the time code is interrupted and errors may occur when editing the tape. To avoid this, refer to "Recording From The Middle Of A Tape" (
 pg. 13).
- To turn the beep sounds off, pg. 25, 27.

LCD Monitor And Viewfinder


While using the LCD monitor:

Make sure the viewfinder is pushed back in. Press the Monitor Opening Button and open the LCD monitor fully. It can rotate 270° (90° downward, 180° upward).

While using the viewfinder:

Make sure the LCD monitor is closed and locked. Pull out the viewfinder fully.

 Be sure to pull out the viewfinder until you hear a click, otherwise it may be pushed back in during use.




NOTES:

- The image will not appear simultaneously on the LCD monitor and the viewfinder. When the viewfinder is pulled out while the LCD monitor is opened, you can select which one to use. Set "PRIORITY" to the desired mode in SYSTEM Menu. (27 pg. 25, 27)
- Colored bright spots may appear all over the LCD monitor or the viewfinder. However, this is not a malfunction.
 (pg. 42)

Tape Remaining Time

Approximate tape remaining time appears on the display. "-h--m" means the camcorder is calculating the remaining time. When the remaining time reaches 2 minutes, the indication starts blinking.



Zooming

Produces the zoom in/out effect, or an instantaneous change in image magnification.


Zoom In

Slide the Power Zoom Lever towards "T".

Zoom Out

Slide the Power Zoom Lever towards "W".

 The further you slide the Power Zoom Lever, the quicker the zoom action



- Focusing may become unstable during Zooming. In this
 case, set the zoom while in Record-Standby, lock the focus
 by using the manual focus (pp. 32), then zoom in or out
 in Record mode.
- Zooming is possible to a maximum of 700X, or it can be switched to 16X (10X for GR-D93) magnification using the optical zoom. (pp. 26)
- Zoom magnification of over 16X (10X for GR-D93) is done through Digital image processing, and is therefore called Digital Zoom.
- During Digital zoom, the quality of image may suffer.
 Digital zoom cannot be used when the VIDEO/MEMORY
- Digital zoom cannot be used when the VIDEO/MEMORY Switch is set to "MEMORY". (GR-D93/73 only)
- Macro shooting (as close as approx. 5 cm (2") to the subject) is possible when the Power Zoom Lever is set all the way to "W". Also see "TELE MACRO" in MANUAL Menu on page 26.

In some situations, different shooting angles may provide more dramatic results. Hold the camcorder in the desired position and tilt the LCD monitor in the most convenient direction. It can rotate 270° (90° downward, 180° upward).



Self Recording


Open the LCD monitor and tilt it upward to 180° so that it faces forward, then point the lens toward yourself and start recording.



Time Code

During recording, a time code is recorded on the tape. This code is to confirm the location of the recorded scene on the tape during playback.

Display



Frames are not displayed during recording. If recording starts from a blank portion, the time code begins counting from "00:00:00" (minute:second:frame). If recording starts from the end of a previously recorded scene, the time code continues from the last time code number.

If during recording a blank portion is left partway through the tape, the time code is interrupted. When recording is resumed, the time code starts counting up again from "00:00:00". This means the camcorder may record the same time codes as those existing in a previously recorded scene. To prevent this, perform "Recording From The Middle Of A Tape" (See the right column) in the following cases:

- When shooting again after playing back a recorded tape.
- When power shuts off during shooting.
- When a tape is removed and re-inserted during shooting.
- When shooting using a partially recorded tape.
- When shooting on a blank portion located partway through
- When shooting again after shooting a scene then opening/ closing the cassette holder cover.

Recording From The Middle Of A Tape


1) Play back a tape or use Blank Search (pp. 14) to find the spot at which you want to start recording, then engage the Still Playback mode. (pg pg. 14)

2) Set the Power Switch to "A" or "M" while pressing down the Lock Button located on the switch, then start recording.


NOTES:


- The time code cannot be reset.
- During fast-forwarding and rewinding, the time code indication does not move smoothly.
- The time code is displayed only when "TIME CODE" is set to "ON". (pg. 27)

When a blank portion is recorded on a tape




Proper recording





VIDEO/MEMORY (GR-D93/73 only)



Normal Playback

Load a cassette. (pg. 10)

2 Set the VIDEO/MEMORY Switch to "VIDEO". (GR-D93/73 only)

3 Set the Power Switch to "PLAY" while pressing down the Lock Button located on the switch.

4 To start playback, press ►/II.

5 To stop playback, press ■.

To control the speaker volume

Rotate the MMENU/VOL. Wheel towards "+" to turn up the volume, or towards "-" to turn down the volume.

NOTES:

- The playback picture can be viewed in the LCD monitor, viewfinder or on a connected TV. (□ pg. 17)
- For other notes, pg. 39.

Still Playback

Pauses during video playback.

- 1) Press ►/II during playback.
- 2) To resume normal playback, press ►/II again.
- If still playback continues for more than about 3 minutes, the camcorder's Stop mode is automatically engaged.
- When >/II is pressed, the image may not pause immediately while the camcorder stabilizes the still image.

Shuttle Search

Allows high-speed search in either direction during video playback.

- 1) During playback, press ►► for forward search, or ◀◀ for reverse search.
- 2) To resume normal playback, press ►/II.
- During playback, press and hold ►► or ◄
 The search continues as long as you hold the button. Once you release the button, normal playback resumes.
- A slight mosaic effect appears on the display during Shuttle Search. This is not a malfunction.

ATTENTION:

During Shuttle Search, parts of the picture may not be clearly visible, particularly on the left side of the screen.



Blank Search

Helps you find where you should start recording in the middle of a tape to avoid time code interruption. (pp. 13)

- Load a cassette. (🖙 pg. 10)
- **2** Set the **VIDEO/MEMORY** Switch to "VIDEO". (GR-D93/73 only)
- **3** Set the Power Switch to "PLAY" while pressing down the Lock Button located on the switch.
- 4 During Stop mode, press BLANK SEARCH.
- The "BLANK SEARCH" indication appears and the camcorder automatically starts reverse or forward search, then stops at the spot which is about 3 seconds of tape before the beginning of the detected blank portion.
- To cancel Blank Search midway, press ■.

- Before starting Blank Search, if the current position is at a blank portion, the camcorder searches in the reverse direction. If the current position is at a recorded portion, the camcorder searches in the forward direction.
- Blank Search does not work if "USE CLEANING CASSETTE" has appeared with the tape.
- If the beginning or end of the tape is reached during Blank Search, the camcorder stops automatically.
- A blank portion which is shorter than 5 seconds of tape may not be detected.
- The detected blank portion may be located between recorded scenes. Before you start recording, make sure there is no recorded scene after the blank portion.

Playback Using The Remote Control (GR-D93/73 only)

The Full-Function Remote Control Unit can operate this camcorder from a distance as well as the basic operations (Playback, Stop. Pause, Fast-Forward and Rewind) of your VCR. It also makes additional playback functions possible. (pg. 16)


Installing The Battery

The remote control uses one lithium battery (CR2025).

Pull out the battery holder by inserting a pointed instrument into the slot.

2 Insert the battery in the holder, and be sure to have the "+" mark visible.

3 Slide the holder back in until vou hear a click.



Beam Effective Area (indoor use)


When using the remote control, be sure to point it at the remote sensor. The transmitted beam's approximate effective distance for indoor use is 5 m (16 ft).

NOTE:

The transmitted beam may not be effective or may cause incorrect Remote sensor operation when the remote sensor

is directly exposed to sunlight or powerful lighting.

Buttons And Functions




Infrared beam transmitting window

The following buttons are available only when the camcorder's Power Switch is set to "PLAY".

0	AUDIO Button(c)	og.	25,	28)
0	PAUSE Button*			
	Up Button	I	pg.	16)
4	SLOW Rewind Button			
6	REW Button* (IF p	og.	14,	20)
	Left Button	I	pg.	16)
0	INSERT Button	IF	pg.	37)
Ø	STOP Button* (F)	og.	14,	20)
	Down Button	ī	pg.	16)
8	SHIFT Button	IF	pg.	16)
9	EFFECT ON/OFF Button			
0	EFFECT Button	IF	pg.	16)
O	SLOW Forward Button	I	pg.	16)
Ø	FF Button* (IF p			
	Right Button	ī	pg.	16)
₿	PLAY Button*(IF p	og.	14,	20)
Ø	A. DUB Button	I	pg.	37)
ø	DISPLAY Button(IF p	og.	17,	34)
		-		

The following buttons are available when the camcorder's Power Switch is set to "A" or "M".

- S.SHOT (Snapshot) Button*
- ② START/STOP Button*
- ③ Zoom (T/W) Buttons** (127 pg. 12, 16)
- Functions the same as each corresponding button on the camcorder. (pg. 51)
- Functions when the camcorder's Power Switch is set to "PLAY" as well.



Slow-Motion Playback

Allows slow-speed search in either direction during video playback.

During normal video playback, press **SLOW** (◀I or I►) more than approx. 2 seconds.

- After approx. 5 minutes (approx. 20 seconds with an 80minute cassette) in Slow Rewind or approx. 5 minutes in Slow Forward, normal playback resumes.
- To pause Slow-Motion playback, press PAUSE (II).
- To stop Slow-Motion playback, press PLAY (►).

NOTES:

- You can also engage Slow-Motion Playback from Still Playback by pressing SLOW (◀I or I►) more than approx.
 2 seconds.
- During Slow-Motion Playback, due to digital image processing, the picture may take on a mosaic effect.
- After SLOW (◀I or I►) is pressed and held, the still image may be displayed for a few seconds, followed by a blue screen for a few seconds. This is not a malfunction.
- There may be a small margin between the slow-motion playback start point you chose and the actual start point for Slow-Motion Playback.
- During Slow-Motion Playback, there will be disturbances in video and the picture may seem unstable, especially with steady images. This is not a malfunction.


Frame-By-Frame Playback

Allows frame-by-frame search during video playback. During normal or still playback, press SLOW (I►) repeatedly for forward or SLOW (◄I) repeatedly for reverse. Each time SLOW (◄I or I►) is pressed, the frame is played back.

Playback Zoom

Magnifies the recorded image up to 44X (70X for GR-D93) at any time during video playback and D.S.C. playback.

1) Press PLAY (►) to start video playback. Or perform normal playback of images.



• To zoom out, press the Zoom Button (W).



3) You can move the image on the screen around to find a particular portion of the picture. While holding down SHIFT, press 【 (Left), 【 (Right), 【 (Up) and 【 (Down).

 To end zoom, press and hold W until magnification returns to normal. Or, press STOP (■) and then press PLAY (►) during video playback.

NOTES:

- Zoom can also be used during slow-motion and still playback.
- Due to digital image processing, the quality of the image may suffer.

Playback Special Effects

Allows you to add creative effects to the video playback image.

The effects that can be used during playback are CLASSIC FILM, MONOTONE, SEPIA and STROBE. The effects work the same in playback as they did in recording. (pg. 30)

₩ CLASSIC FILM: Gives recorded scenes a strobe effect.

B/W MONOTONE: Like classic black and white films, your footage is shot in B/W. Used together with the Cinema mode, it enhances the "classic film" effect.

SEPIA: Recorded scenes have a brownish tint like old photos. Combine this with the Cinema mode for a classic look.

STROBE: Your recording looks like a series of consecutive snapshots.

1) To start playback, press PLAY (▶).
2) Press EFFECT.
The PLAYBACK
EFFECT Select Menu appears.


appears.
3) Press EFFECT
repeatedly to move
the highlight bar to the
desired effect.



- The selected function is activated and after 2 seconds the menu disappears.
- To deactivate the selected effect, press EFFECT ON/OFF.
 To reactivate the selected effect press EFFECT ON/OFF again.
- To change the selected effect, repeat from step 2 above.

Connections To A TV Or VCR

These are some basic types of connections. When making the connections, refer also to your VCR and TV instruction manuals.



- White to AUDIO L IN*
- 2 Red to AUDIO R IN*
- To S-VIDEO IN***
- * Not required for watching still images only.
- ** Connect when your TV/VCR has only A/V input connectors.
- *** Connect when your TV/VCR has S-VIDEO IN and A/V input connectors. In this case, it is not necessary to connect the yellow video cable.

- 1 Make sure all units are turned off.
- 2 Connect the camcorder to a TV or VCR as shown in the illustration

If using a VCR, go to step 3. If not, go to step 4.

- **3** Connect the VCR output to the TV input, referring to your VCR's instruction manual.
- 4 Turn on the camcorder, the VCR and the TV.
- **5** Set the VCR to its AUX input mode, and set the TV to its VIDEO mode.

To choose whether or not the following displays appear on the connected TV

- Date/Time
- Set "DATE/TIME" to "AUTO", "ON" or "OFF". (pg. 25, 28) Or, press **DISPLAY** on the remote control (provided with GR-D93/73 only) to turn on/off the date indication.
- Time Code Set "TIME CODE" to "ON" or "OFF". (☞ pg. 25, 28)
- Indications other than date/time and time code Set "ON SCREEN" to "OFF", "LCD" or "LCD/TV".
 (IF) pg. 25, 28)

- It is recommended to use the AC Adapter as the power supply instead of the battery pack. (□ pg. 7)
- To monitor the picture and sound from the camcorder without inserting a tape or memory card*, set the camcorder's Power Switch to "A" or "M", then set your TV to the appropriate input mode.
 * GR-D93/73 only
- Make sure you adjust the TV sound volume to its minimum level to avoid a sudden burst of sound when the camcorder is turned on.
- If you have a TV or speakers that are not specially shielded, do not place the speakers adjacent to the TV as interference will occur in the camcorder playback picture.
- When a cable is connected to the AV connector, the sound is not heard from the speaker.


Basic Shooting (D.S.C. Snapshot)

You can use your camcorder as a Digital Still Camera for taking snapshots. Still images are stored in the memory card

NOTE:

Before continuing, perform the procedures listed below:

- Power (□ pq. 6)
- Loading A Memory Card (□ pg. 10)



- Remove the lens cap.
- 2 Open the LCD monitor fully. (pg. 12)
- 3 Set the VIDEO/MEMORY Switch to "MEMORY".
- **4** Set the Power Switch to "\mathbb{\mathbb{A}}" or "\mathbb{\mathbb{M}}" while pressing down the Lock Button located on the switch.
- To change the Image Size and/or Picture Quality, pg. 25, 27.
- **5** Press **SNAPSHOT**. The "**PHOTO**" indication appears while the snapshot is being taken.
- Still images are recorded in the snapshot mode with no frame.
- To delete unwanted still images, refer to "Deleting Files" (pg. 22).
- When you do not want to hear the shutter sound, set "BEEP" to "OFF". (IFF pg. 25, 27)



Snapshot mode with no frame

There is the sound of a shutter closing.


- 1 Image Size (□ pg. 28. 52)
- Shooting Icon (pg. 52)
- 3 Card Icon (pg. 52)
- Picture Quality (pg. 27, 52)
- **5** Remaining Number Of Shots (pp. 52)

Approximate Number of Storable Images

			-		
Image Size/Picture	SD Memory Card				
Quality	8 MB*	16 MB*	32 MB*	64 MB*	
640 x 480/FINE	45	95	205	405	
640 x 480/ STANDARD	160	295	625	1215	
1024 x 768/FINE	20	45	95	190	
1024 x 768/ STANDARD	65	145	310	605	
1280 x 960/ FINE***	13	29	60	125	
1280 x 960/ STANDARD***	45	95	205	425	
1600 x 1200/ FINE***	8	19	41	80	
1600 x 1200/ STANDARD***	28	60	130	275	

Image Size/Picture Quality	MultiMediaCard			
	8 MB**	16 MB*	32 MB*	
640 x 480/FINE	55	105	215	
640 x 480/STANDARD	190	320	645	
1024 x 768/FINE	24	48	100	
1024 x 768/STANDARD	75	160	320	
1280 x 960/FINE***	16	32	60	
1280 x 960/STANDARD***	50	105	215	
1600 x 1200/FINE***	10	21	42	
1600 x 1200/STANDARD***	34	65	135	

- Optional
- ** Provided
- *** GR-D93 only



Dubbing Still Images Recorded On A Tape To A Memory Card


Still images can be dubbed from a tape to a memory

- Load a cassette. (F pg. 10)
- 2 Load a memory card. (pg. 10)
- 3 Set the VIDEO/MEMORY Switch to "VIDEO".
- **4** Set the Power Switch to "PLAY" while pressing down the Lock Button located on the switch.
- 5 Set " → M COPY" to "ON". (🖙 pg. 25, 28)
- 6 Press ►/II to start playback.
- **7** At the point you want to dub, press ►/II again to engage Still Playback.
- **8** To dub the image, press **SNAPSHOT**.
- The "➡™" indication appears during dubbing.
- The selected image is stored in the memory card.

- If SNAPSHOT is pressed in step 8 when a memory card is not loaded, the message "COPYING FAILED" is displayed.
- If an image recorded on the tape using "WIDE MODE"
 (pg. 26) is dubbed to a memory card, the WIDE mode identifying signal is not dubbed with it.
- To use Playback Special effects with a video image you wish to dub, perform up to step 8 using the remote control (provided). (□ pq. 16)
- Images are dubbed in 640 x 480 pixels.

Normal Playback Of Images

Images shot with the camcorder are automatically numbered, then stored in numerical order in the memory card. You can view the stored images, one at a time, much like flipping through a photo album.



- Load a memory card. (pg. 10)
- 2 Set the VIDEO/MEMORY Switch to "MEMORY".
- **3** Set the Power Switch to "PLAY" while pressing down the Lock Button located on the switch.
- A stored image is displayed.
- **4** Press **◄** to display the previous file. Press **▶▶** to display the next file.
- Pressing INFO gives you details on the displayed file.
 pg. 21)
- You can also look for the desired file using Index Screen. (See the right column)
- You can turn off the on-screen playback display. (pg. 21)

NOTES:

- Even if you shoot a new image after playing back a lownumbered one, this will not overwrite an existing image, because new images are automatically stored after the lastrecorded one.
- Images shot in a file size other than "640 x 480", "1024 x 768", "1280 x 960"* and "1600 x 1200"* with another devices will be displayed thumbnail images. These thumbnail images cannot be transferred to a PC.
 * GR-D93 only
- Images shot with devices (such as JVC GR-DVM70) that are not compatible with DCF cannot be viewed with this camcorder; "UNSUPPORTED FILE!" will be displayed.


Playback Zoom

Available only with the remote control (provided). (provided).

Auto Playback Of Images

You can run through all the images stored in memory card automatically.

- Perform steps 1 3 in "Normal Playback Of Images".
- 2 Press ►/II to start Auto Playback.
- If you press ◄◄ during Auto Playback, files are displayed in descending order.
- If you press b during Auto Playback, files are displayed in ascending order.



Index Playback Of Files

You can view several different files stored in the memory card at a time. This browsing capability makes it easy to locate a particular file you want.

- Perform steps 1 3 in "Normal Playback Of Images".
- **2** Press **INDEX**. The Index Screen appears.
- **3** Rotate the MMENU/VOL. Wheel to move the frame to the desired file.
- Press ◄ to display the previous page. Press ► to display the
- next page. **4** Press the MMENU/VOL.

 Wheel in. The selected file is
- displayed.

 Pressing INFO gives you details on the displayed file.

 (☞ pg. 21)





Index number

Viewing File Information

You can get the relevant file information by pressing the INFO Button during normal playback or Index Playback.

FOLDER: Folder name (pg. 24)
FILE: File name (pg. 24)
DATE: Date the file was made

SIZE: Image size
QUALITY: Picture quality

PROTECT: When set to "ON", the file is protected from accidental

erasure. (F pg. 22)

 Press the INFO Button again to close the Information Screen.


NOTE:

With images shot with other devices or processed on a PC, "QUALITY: ---" will be displayed.

Removing On-Screen Display

- Perform steps 1 3 in "Normal Playback Of Images" (□ pg. 20).
- **2** Press the MMENU/VOL. Wheel in. The Menu Screen appears.
- **3** Rotate the MMENU/VOL. Wheel to select "DISPLAY", and press it. The Sub Menu appears.
- 4 Rotate the MENU/VOL. Wheel to select "OFF", and press it. The operation mode indicator, folder/file number and battery indicator (••••••••) disappear.
- To display the indicators again, select "ON".

Operation mode indicator



Battery indicator

Protecting Files

The Protect mode helps prevent the accidental erasure of files.

- Load a memory card. (pg. 10)
- 2 Set the VIDEO/MEMORY Switch to "MEMORY".
- **3** Set the Power Switch to "PLAY" while pressing down the Lock Button located on the switch.
- A stored file is displayed.
- **4** Press the MMENU/VOL. Wheel in. The Menu Screen appears.
- **5** Make sure "PROTECT" is selected, and press the MMENU/VOL. Wheel in. The Sub Menu appears.

To protect the currently displayed file

6 Rotate the MMENU/VOL. Wheel to select "CURRENT", and press it. The PROTECT screen appears.

7 Press **◄** or **▶▶** to select the desired file.

8 Rotate the MMENU/VOL. Wheel to select "EXECUTE", and press it.

- To cancel protection, select "RETURN".
- Repeat steps 7 and 8 for all files you want to protect.

«MENU» PROTECT DELETE DPOF NO. RESET FORMAT DISPLAY BRIGHT END



RETURN

«MENU» PROTECT CURRENT

To protect all files stored in the memory card

6 Rotate the **MMENU/VOL.** Wheel to select "PROT.ALL", and press it. The PROTECT screen appears.

7 Rotate the MMENU/VOL. Wheel to select "EXECUTE", and press it.

• To cancel protection, select "RETURN".

NOTES:

- If the "⊚¬" mark appears, the currently displayed file is protected.
- When the memory card is initialized or corrupted, even protected files are deleted. If you do not want to lose important files, transfer them to a PC and save them.

To Remove Protection

Before doing the following, perform steps $\mathbf{1} - \mathbf{5}$ in "Protecting Files".

To remove protection from the currently displayed file


- 6 Rotate the MMENU/VOL. Wheel to select "CURRENT", and press it. The PROTECT screen appears.
- **7** Press **◄** or **▶** to select the desired file.
- **8** Rotate the **MMENU/VOL**. Wheel to select "EXECUTE", and press it.
- To cancel selection, select "RETURN".
- Repeat steps 7 and 8 for all files you want to remove protection.

To remove protection from all files stored in the memory card

- **6** Rotate the MMENU/VOL. Wheel to select "CANC.ALL", and press it. The PROTECT screen appears.
- **7** Rotate the MMENU/VOL. Wheel to select "EXECUTE", and press it.
- To cancel selection, select "RETURN".

Deleting Files

Previously stored files can be deleted either one at a time or all at once.



- Load a memory card. (pg. 10)
- 2 Set the VIDEO/MEMORY Switch to "MEMORY".
- **3** Set the Power Switch to "PLAY" while pressing down the Lock Button located on the switch.
- A stored file is displayed.
- **4** Press the MENU/VOL. Wheel in. The Menu Screen appears.
- **5** Rotate the MMENU/VOL. Wheel to select "DELETE", and press it. The Sub Menu appears.

To delete the currently displayed file

♠ Rotate the MMENU/VOL. Wheel to select "CURRENT", and press it. The DELETE screen appears.

7 Press **◄** or **▶** to select the desired file.

8 Rotate the MMENU/VOL. Wheel to select "EXECUTE", and press it.

- To cancel deletion, select "RETURN".
- Repeat steps 7 and 8 for all files you want to delete.





NOTE:

If the " $@_m$ " mark appears, the selected file is protected and cannot be deleted.

To delete all files stored in the memory card

6 Rotate the **MENU/VOL**. Wheel to select "ALL", and press it. The DELETE screen appears.

- **7** Rotate the **MMENU/VOL**. Wheel to select "EXECUTE", and press it.
- To cancel deletion, select "RETURN".

NOTES:

- Protected files (pg. 22) cannot be deleted. To delete them, remove protection first.
- Once files are deleted, they cannot be restored. Check files before deleting.

CAUTION:

Do not remove the memory card or perform any other operation (such as turning off the camcorder) during deletion. Also, be sure to use the provided AC Adapter, as the memory card may be corrupted if the battery becomes exhausted during deletion. If the memory card becomes corrupted, initialize it. (27 pg. 24)

Setting Print Information (DPOF Setting)

This camcorder is compatible with the DPOF (Digital Print Order Format) standard in order to support future systems such as automatic printing. You can select one of the 2 print information settings for images stored in the memory card: "To Print All Still Images (One Print For Each)" or "To Print By Selecting Still Images And Number Of Prints".

NOTES:

- If you load a memory card already set as shown below in a printer compatible with DPOF, it will make prints of the selected still images automatically.
- To print images recorded on a tape, first dub them to a memory card. (pp pg. 19)

To Print All Still Images (One Print For Each)

- Load a memory card. (pg. 10)
- **2** Set the **VIDEO/MEMORY** Switch to "MEMORY".
- **3** Set the Power Switch to "PLAY" while pressing down the Lock Button located on the switch.
- A stored file is displayed.
- **4** Press the MMENU/VOL. Wheel in. The Menu Screen appears.
- **5** Rotate the MMENU/VOL. Wheel to select "DPOF", and press it. The Sub Menu appears.
- **6** Rotate the MMENU/VOL. Wheel to select "ALL 1", and press it. The DPOF screen appears.
- **7** Rotate the MMENU/VOL. Wheel to select "EXECUTE", and press it. The normal playback screen appears.
- To cancel selection, select "RETURN".





To Print By Selecting Still Images And Number Of Prints

- **1** Perform steps 1 5 in "To Print All Still Images (One Print For Each)".
- **2** Rotate the MMENU/VOL. Wheel to select "CURRENT", and press it. The DPOF screen appears.
- **3** Press **◄** or **▶** to select the desired file.
- 4 Rotate the MENU/VOL. Wheel to select the number indication (00), and press it.
- **5** Select the number of prints by rotating the MMENU/VOL. Wheel towards "+" to increase number, or towards "-" to decrease the number, and press it.
- Repeat steps 3 through 5 for the desired number of prints.
- The number of prints can be set up to 15.
- To correct the number of prints, select the image again and change the number.
- **6** Rotate the **MENU/VOL**. Wheel to select "RETURN", and press it. The "SAVE?" appears.
- If you did not change any settings in step 3 through 5, the Menu Screen reappears.
- in save?
 EXECUTE
 CANCEL

SHEETS

00 RETURN

0.5

- **7** Rotate the MENU/VOL. Wheel to select "EXECUTE" to save the setting you have just made, and press it.
- To cancel selection, select "CANCEL".

To Reset The Number Of Prints

- **1** Perform steps 1 5 in "To Print All Still Images (One Print For Each)".
- **2** Rotate the MMENU/VOL. Wheel to select "RESET", and press it. The DPOF screen appears.
- **3** Rotate the MMENU/VOL. Wheel to select "EXECUTE", and press it. The normal playback screen appears.
- To cancel selection, select "RETURN".
- The number of prints is reset to 0 for all still images.

CAUTION:

While performing the above, never disconnect power, as this may cause the memory card to be corrupted.

Resetting The File Name

By resetting the file name, a new folder will be made. The new files you are going to make will be stored in the new folder. It is convenient to separate the new files from previously made files.

- Load a memory card. (pg. 10)
- 2 Set the VIDEO/MEMORY Switch to "MEMORY".
- **3** Set the Power Switch to "PLAY" while pressing down the Lock Button located on the switch.
- A stored file is displayed.
- **4** Press the MMENU/VOL. Wheel in. The Menu Screen appears.
- **5** Rotate the MMENU/VOL. Wheel to select "NO. RESET", and press it. The NO. RESET screen appears.
- 6 Rotate the MMENU/VOL. Wheel to select "EXECUTE", and press it. The new folder (such as "101JVCGR") will be made and the file name of the next shot starts from DVC00001

Folder and File names

Each time shooting takes place, a file name is made using a number which is larger by one than the largest number of the file names which are in use. Even if you delete an image or video clip file with a number in the middle of range, the number will not be used for a new shot; a gap will remain in the numerical sequence. If the file name reaches DVC09999, a new folder (such as "101JVCGR") will be made and the file name will start again from DVC00001.

Initializing A Memory Card

You can initialize a memory card anytime.

After initializing, all files and data stored in the memory card, including those which have been protected, are

- 1 Set the VIDEO/MEMORY Switch to "MEMORY".
- **2** Set the Power Switch to "PLAY" while pressing down the Lock Button located on the switch.
- 3 Open the LCD monitor fully. (cr pg. 12)
- **4** Press the MMENU/VOL. Wheel in. The Menu Screen appears.

cleared.

- **5** Rotate the MMENU/VOL. Wheel to select "FORMAT", and press it. The FORMAT screen appears.
- **6** Rotate the MMENU/VOL. Wheel to select "EXECUTE", and press it. The memory card is initialized
- When initialization is finished, "NO IMAGES STORED" appears.

«FORMAT»

ERASE ALL

EXECUTE


• To cancel initialization, select "RETURN".

CAUTION:

Do not perform any other operation (such as turning off the camcorder) during initialization. Also, be sure to use the provided AC Adapter, as the memory card may be corrupted if the battery becomes exhausted during initialization. If the memory card becomes corrupted initialize it.

Changing The Menu Settings

This camcorder is equipped with an easy-to-use, onscreen menu system that simplifies many of the more detailed camcorder settings. (pg. 26 - 28)



VIDEO/MEMORY (GR-D93/73 only)

1 Set the VIDEO/MEMORY Switch (GR-D93/73 only) and the Power Switch as follows.

For Video and D.S.C. (GR-D93/73 only) Recording Menus:

- Set the VIDEO/MEMORY Switch to "VIDEO" or "MEMORY". (GR-D93/73 only)
- Set the Power Switch to "M" while pressing down the Lock Button located on the switch.

For Video Playback Menus:

- Set the VIDEO/MEMORY Switch to "VIDEO". (GR-D93/73 only)
- Set the Power Switch to "PLAY" while pressing down the Lock Button located on the switch.
- For D.S.C. Playback Menus, refer to "D.S.C. PLAYBACK (GR-D93/D73 only)" (pg. 20).
- 2 Open the LCD monitor fully. (pg. 12)
- 3 Press the MMENU/VOL. Wheel in. The Menu Screen appears.
- 4 Rotate the MMENU/VOL. Wheel to select the desired function, and press it. The selected function menu appears.

Screen for Video and D.S.C. Screen for Video Playback Recording Menu





5 Setting procedure hereafter depends on the selected function.

Menus without Sub Menus

WIPE/FADER (□ pq. 30) PROGRAM AE (pg. 30) EXPOSURE (pg. 32) ₩. BALANCE(pg. 33)

- 1) Rotate the MMENU/VOL. Wheel to select the desired parameter.
- Example: PROGRAM AE Menu
- 2) Press the MMENU/VOL. Wheel in. Selection is complete. The Menu Screen returns.
- Repeat the procedure if you wish to set other function menus
- 3) Press the MMENU/VOL. Wheel in again. The Menu Screen closes

Menus with Suh Menus

 MANUAL (□ pq. 26) SYSTEM (□ pq. 27) CAMERA DISPLAY

(c pq. 27)


DSC (GR-D93/73 only) (c pg. 27)

VIDEO (□ pq. 28) ☑ VIDEO DISPLAY (
☐ pq. 28)

- 1) Rotate the MMENU/VOL. Wheel to select the desired function, and press it. The Sub Menu appears.
- Example: A CAMERA Menu Rotate the MMENU/VOL. Wheel to select the desired parameter.
- 3) Press the MMENU/VOL. Wheel in. Selection is complete.
- Repeat the procedure if you wish to set other function menus.
- Press the MMENU/VOL. Wheel in. The Menu Screen
- returns. Repeat the procedure if you wish to set other function menus.
- Press the MMENU/VOL. Wheel in again. The Menu Screen closes.

Selected menu icon blinks.









Sub Menu





Recording Menus

CAMERA

The "A" settings are effective when the Power Switch is set to both "A" and "M". However, the menu settings can be changed only when the Power Switch is set to "M".

1 = Factory-preset

REC MODE

[SP]: To record in the SP (Standard Play) mode **LP**: Long Play—more economical, providing 1.5 times the recording time.

NOTES:

- Audio Dubbing (pp. 37) and Insert Editing (pp. 37) are possible on tapes recorded in the SP mode. (GR-D93/73 only)
- If the recording mode is switched, the playback picture will be blurred at the switching point.
- It is recommended that tapes recorded in the LP mode on this camcorder be played back on this camcorder.
- During playback of a tape recorded on another camcorder, blocks of noise may appear or there may be momentary pauses in the sound.

SOUND MODE

[12 bit]: Enables video recording of stereo sound on four separate channels, and is recommended for use when performing Audio Dubbing. (Equivalent to the 32 kHz mode of previous models)

16 bit: Enables video recording of stereo sound on two separate channels. (Equivalent to the 48 kHz mode of previous models)

ZOOM

16X (GR-D73/33), **10X** (GR-D93): When set to "16X" ("10X" for GR-D93) while using digital zoom, the zoom magnification will reset to 16X ("10X" for GR-D93) since digital zoom will be disengaged.

[40X]*: Allows you to use the Digital Zoom. By digitally processing and magnifying images, zooming is possible from 16X (10X for GR-D93) (the optical zoom limit), to a maximum of 40X digital magnification.

700X*: Allows you to use the Digital Zoom. By digitally processing and magnifying images, zooming is possible from 16X (10X for GR-D93) (the optical zoom limit), to a maximum of 700X digital magnification.

 Available only when the VIDEO/MEMORY Switch is set to "VIDEO". (GR-D93/73 only)

SNAP MODE

[FULL]: Snapshot mode with no frame **PIN-UP**: Pin-Up mode

FRAME: Snapshot mode with frame







[FULL]

PIN-UP

FRAME

For details on the procedure, refer to "Snapshot (For Video Recording)" (pg. 31).

GAIN UP

OFF: Allows you to shoot dark scenes with no picture brightness adjustment.

[AGC]: The overall appearance may be grainy, but the image is bright.

AUTO → A: A: The shutter speed is automatically adjusted. Shooting a subject in low or poor lighting at slow shutter speed provides a brighter image than in the AGC mode, but the subject's movements are not smooth or natural. The overall appearance may be grainy. While the shutter speed is being automatically adjusted, "→ A" is displayed.

I MANUAL

The " \blacksquare " settings are effective only when the Power Switch is set to " \blacksquare ".

[] = Factory-preset

DIS

OFF: Disables the function.

[ON (4)]: To compensate for unstable images caused by camera-shake, particularly at high magnification.

NOTES:

- Accurate stabilization may not be possible if hand shake is excessive, or under the following conditions:
 - When shooting subjects with vertical or horizontal stripes.
 - · When shooting dark or dim subjects.
- · When shooting subjects with excessive backlighting.
 - When shooting scenes with movement in various directions.
- When shooting scenes with low-contrast backgrounds.
 Switch off this mode when recording with the camcorder on
- The "((1))" indicator blinks or goes out if the Stabilizer cannot be used.

TELE MACRO

[OFF]: Disables the function.

ON: Usually the distance to a subject where the lens is in focus depends on the zoom magnification. Unless there is a distance more than 1 m (3.3 ft) to the subject, the lens is out of focus at the maximum telephoto setting. When set to "ON", you can shoot a subject as large as possible at a distance of approx. 60 cm (2 ft).

NOTE:

Depending on the zoom position, the lens may go out of focus.

WIDE MODE

[OFF]: Records with no change in the screen ratio. For playback on a TV with a normal screen ratio.

CINEMA*□: Inserts black bands at the top and bottom of the screen. The □ indicator appears. During playback on wide-screen TVs, the black bands at the top and bottom of the screen are cut and the screen ratio becomes 16:9. When using this mode, refer to your wide-screen TV's instruction manual. During playback/ recording on 4:3 TVs/LCD monitor/viewfinder, black bands are inserted at the top and bottom of the screen and the image appears like a letter boxed 16:9 movie.

SQUEEZE*□: For playback on TVs with an aspect ratio of 16:9. Naturally expands the image to fit the screen without distortion. The □ indicator appears. When using

this mode, refer to your wide-screen TV's instruction manual. During playback/recording on 4:3 TVs/LCD monitor/viewfinder. the image is elongated vertically.

* Available only when the VIDEO/MEMORY Switch is set to "VIDEO". (GR-D93/73 only)

WIND CUT

[OFF]: Disengages the function.

ON (: Helps cut down on noise created by wind. The (" indicator appears. The quality of the sound will change. This is normal.

SYSTEM

The "A" functions which are set when the Power Switch is set to "M" are also applied when the Power Switch is set to "PLAY".

[] = Factory-preset

BEEP

OFF: Turns off sounds when performing any operations. It also deactivates the shutter sound effect, however the shutter sound is recorded onto the tape during Snapshot for Video Recording (pp. 31).

BEEP: The beep sounds when the power is turned on or off, and at the beginning and end of recording. It also activates the shutter sound effect. (pr pg. 18, 31) [MELODY]: Instead of a beep, a melody sounds when any operation is performed. It also activates the shutter

REMOTE

sound effect. (pg. 18, 31)

OFF: Disables the remote control operations. **[ON]**: Enables the remote control operations. For GR-D33 owners: It is recommended that this function be set to "OFF" to prevent improper operation.

DEMO MODE

OFF: Automatic demonstration will not take place. **[ON]**: Demonstrates certain functions such as Program AE with special effects, etc., and can be used to confirm how these functions operate. Demonstration starts in the following cases:

- When the Menu Screen is closed after "DEMO MODE" is turned "ON".
- With "DEMO MODE" set to "ON", if there is no operation for about 3 minutes after the Power Switch is set to "\(\frac{m}{2} \)" or "\(\frac{m}{2} \)".
 Performing any operation during the demonstration stops the demonstration temporarily. If no operation is performed for more than 3 minutes after that, the demonstration will resume.

NOTES:

- If a cassette is in the camcorder, the demonstration cannot be turned on.
- "DEMO MODE" remains "ON" even if the camcorder power is turned off.
- If "DEMO MODE" remains "ON", some functions will not be available. After viewing demo, set to "OFF".

PRIORITY

[LCD]: The image is displayed on the LCD monitor when the viewfinder is pulled out while the LCD monitor is opened. **FINDER**: The image is displayed in the viewfinder when the viewfinder is pulled out while the LCD monitor is opened.

CAM RESET

EXECUTE: Resets all settings to the factory-preset. **RETURN**: Does not reset all settings to the factory-preset.

CAMERA DISPLAY

- The "②" (CAMERA DISPLAY) settings are effective even when the Power Switch is set to "△". However, the menu settings can be changed only when the Power Switch is set to "™".
- The "O" (CAMERA DISPLAY) settings are effective only for shooting except "BRIGHT".

[] = Factory-preset

BRIGHT

r pg. 9, "Brightness Adjustment Of The Display"

ON SCREEN

LCD: Keeps the camcorder's display (except the date, time and time code) from appearing on the connected TV screen.

[LCD/TV]: Makes the camcorder's display appear on screen when the camcorder is connected to a TV.

DATE/TIME

OFF: The date/time does not appear.

[AUTO]: Displays the date/time for approx. 5 seconds when the Power Switch is set from "OFF" to "A" or "M". ON: The date/time is always displayed.

 The date indication can also be turned on/off by pressing the DISPLAY Button on the remote control (provided with GR-D93/73 only). (prop. 17, 34)

TIME CODE

[OFF]: Time code is not displayed.

ON: Time code is displayed on the camcorder and on the connected TV. Frame numbers are not displayed during recording. (Frame pg. 13)

CLOCK ADJ.

pg. 8, "Date/Time Settings"

OSC (GR-D93/73 only)

[] = Factory-preset

QUALITY

[FINE] / STANDARD

The Picture Quality mode can be selected to best match your needs. Two Picture Quality modes are available: FINE () and STANDARD () (in order of quality).

NOTE:

The number of storable images depends on the selected picture quality as well as the composition of the subjects in the images and the type of memory card being used. (pp. 18)

IMAGE SIZE

GR-D73: 640 x 480 / [1024 x 768]

GR-D93: 640 x 480 / 1024 x 768 / [1280 x 960] /

1600 x 1200

The Image Size mode can be selected to best match your needs. (pp. 18)

NOTE:

The settings can be changed only when the **VIDEO/ MEMORY** Switch is set to "MEMORY"

REC SELECT

[______]: When Snapshot recording is performed with the VIDEO/MEMORY Switch set to "VIDEO", still images are recorded only onto the tape.

→ M: When Snapshot recording is performed with the VIDEO/MEMORY Switch set to "VIDEO", still images are recorded not only onto the tape but also in the memory card (640 x 480 pixels). In this mode, the "SNAP MODE" selection in CAMERA Menu is also applicable to memory card recording.

Playback Menus

■ VIDEO

[] = Factory-preset

SOUND MODE and NARRATION

During tape playback, the camcorder detects the sound mode in which the recording was made, and plays the sound back. Select the type of sound to accompany your playback picture. According to the menu access explanation on page 25, select "SOUND MODE" or "NARRATION" from the Menu Screen and set it to the desired parameter.

SOUND MODE

[STEREO ►]: Sound is output on both "L" and "R" channels in stereo.

SOUND L D: Sound from the "L" channel is output. SOUND R ☐: Sound from the "R" channel is output.

NARRATION

[OFF]: Original sound is output on both "L" and "R" channels in stereo.

ON: Dubbed sound is output on both "L" and "R" channels in stereo.

MIX: Original and dubbed sounds are combined and output in stereo on both "L" and "R" channels.

NOTES:

- For GR-D93/73 Owners: You can also use AUDIO button on the provided remote control (propring pg. 15) to change the output sound (without having to access the Playback Menu).
- The "SOUND MODE" setting is available for both 12-bit and 16-bit sound. (In previous models' functions, "12-bit" is called "32 kHz" and "16-bit" is called "48 kHz".)
- The camcorder cannot detect the sound mode in which the recording was made during fast-forward or rewind. During playback the sound mode is displayed in the upper left corner.

REC MODE [SP] / LP

Allows you to set the video recording mode (SP or LP) depending on your preference. It is recommended you use "REC MODE" in VIDEO Menu when using this camcorder as a recorder during dubbing. (pp. 34, 35)

NOTE:

"REC MODE" can be set when the Power Switch is set to "PLAY" or " $\mbox{$\mathbb{M}$}$ ".

COPY (GR-D93/73 only)

[OFF]: When the SNAPSHOT button is pressed during tape playback, the playback image pauses and normal playback will resume after approximately 6 seconds. (The still image is not recorded.)

ON: Enables dubbing of images recorded on a tape to a memory card. (pg. 19)

S/AV INPUT (GR-D93/73 only)

[OFF]: Disables audio/video signal input from the AV and S-Video connectors. (
pg. 34)

ON: Enables audio/video signal input from the AV and S-Video connectors. (pg. 34)

SYSTEM

Each setting is linked with "A", which appears when the Power Switch is set to "M". (pg. 25)

 The parameters are the same as in the description on page 27.

[] = Factory-preset

DEEP / [MELODY]

REMOTE OFF / [ON]

DEMO MODE OFF / [ON]

PRIORITY [LCD] / FINDER

CAM RESET EXECUTE / RETURN

O VIDEO DISPLAY

The "O" (VIDEO DISPLAY) settings are effective only for video playback except "BRIGHT".

• The parameters (except "OFF" in ON SCREEN settings) are the same as in the description on page 27.

[] = Factory-preset

BRIGHT

☐ pg. 9, "Brightness Adjustment Of The Display"

ON SCREEN OFF / [LCD] / LCD/TV


When set to "OFF", the camcorder's display disappears.

DATE/TIME [OFF] / AUTO / ON

When set to "AUTO", the date/time are displayed in the following cases:

- When playback starts. The camcorder displays the date/ time when scenes are recorded.
- When the date is changed during playback.

TIME CODE [OFF] / ON



White LED Light

White LED Light can be used to brighten the subject in the dark place during video recording or D.S.C. shooting.

Press LIGHT repeatedly to change the setting.

OFF: Turns off the light.

ON: The light is on always. (appears.)

AUTO: The light turns on automatically when dark.

(३ A appears.)

2 Press the Recording Start/Stop Button to start video recording or **SNAPSHOT** to shoot a still image.

NOTES:

- Be careful not to point the LED Light directly to eyes.
- If the light does not reach the subject, the Night-Alive function will be activated, and makes it possible to shoot the subject brighter.
- There is a difference in the brightness of the images shot between the centre area which is illuminated by the LED Light and the surrounding areas (which will be darker).
- Since subjects are shot at a reduced shutter speed when the White LED Light setting is "ON", they will appear slightly blurred.

Night Alive

Makes dark subjects or areas even brighter than they would be under good natural lighting. Although the recorded image is not grainy, it may look as if it is strobing due to the slow shutter speed.

Set the Power Switch to "M" while pressing down the Lock Button located on the switch.

2 Open the LCD monitor fully. (car pg. 12)

3 Press NIGHT so that the Night-Alive indicator " appears.

- The shutter speed is automatically adjusted to provide up to 30 times sensitivity.
- "A" appears beside "oo" while the shutter speed is being automatically adjusted.

To deactivate Night-Alive

Press **NIGHT** again so that the Night-Alive indicator disappears.

- During Night-Alive, the following functions or settings cannot be activated and its indicator blinks or goes out:
 - Some modes of "Program AE With Special Effects" (pg. 30).
 - "GAIN UP" in CAMERA Menu. (pg. 26)
 - "DIS" in MANUAL Menu. (pg. 26)
- During Night-Alive, it may be difficult to bring the camcorder. into focus. To prevent this, use of a tripod is recommended.

Wipe Or Fader Effects

IMPORTANT:

Some Wipe/Fader Effects cannot be used with certain modes of Program AE with special effects. (See the right column) If an unusable Wipe/Fader Effect is selected, its indicator blinks in blue or goes out.

These effects let you make pro-style scene transitions. Use them to spice up the transition from one scene to the next.

Wipe or Fader works when video recording is started or stopped.

1 Set the **VIDEO/MEMORY** Switch to "VIDEO". (GR-D93/73 only)

2 Set the Power Switch to "M" while pressing down the Lock Button located on the switch.

3 Open the LCD monitor fully. (pg. 12)

4 Set "s" to the desired mode. (pp. 25)

- The WIPE/FADER menu disappears and the effect is reserved
- The selected effect indicator appears.
- **5** Press the Recording Start/Stop Button to activate the Fade-in/out or Wipe-in/out.

To deactivate the selected effect

Select "OFF" in step 4. The effect indicator disappears.

NOTE:

You can extend the length of a Wipe or Fader by pressing and holding the Recording Start/Stop Button.

■ WIPE/FADER

OFF: Disables the function. (Factory-preset)

WH FADER-WHITE: Fade in or out with a white screen.

BK FADER-BLACK: Fade in or out with a black screen.

<u>B.W.</u> FADER-B.W: Fade in to a color screen from a black and white screen, or fade out from color to black and white

WIPE-CORNER: Wipe in on a black screen from the upper right to the lower left corner, or wipe out from lower left to upper right, leaving a black screen.

WIPE-WINDOW: The scene starts in the center of a black screen and wipes in toward the corners, or comes in from the corners, gradually wiping out to the center.

WIPE-SLIDE: Wipe in from right to left, or wipe out from left to right.

WIPE-DOOR: Wipe in as the two halves of a black screen open to the left and right, revealing the scene, or wipe out and the black screen reappears from left and right to cover the scene.

WIPE-SCROLL: The scene wipes in from the bottom to the top of a black screen, or wipes out from top to bottom, leaving a black screen.

WIPE-SHUTTER: Wipe in from the center of a black screen toward the top and bottom, or wipe out from the top and bottom toward the center leaving a black screen.

Program AE With Special Effects

IMPORTANT:

Some modes of Program AE with special effects cannot be used with certain Wipe/Fader effects. (See the left column) If an unusable mode is selected, the indicator of Program AE with Special Effects blinks or goes out.

1 Set the Power Switch to "M" while pressing down the Lock Button located on the switch.

2 Open the LCD monitor fully. (pg. 12)

3 Set "" to the desired mode. (pp. 25)

 The PROGRAM AE menu disappears and the selected effect is activated.

• The selected effect indicator appears.

To deactivate the selected effect

Select "OFF" in step 3. The effect indicator disappears.

NOTES:

- Program AE with special effects can be changed during recording or during Record-Standby.
- Some modes of Program AE with special effects cannot be used during Night-Alive.

PROGRAM AE

OFF: Disables the function. (Factory-preset)

1/60 SHUTTER 1/60: The shutter speed is fixed at 1/60th of a second. Black bands that usually appear when shooting a TV screen become narrower.

1/100 SHUTTER 1/100: The shutter speed is fixed at 1/100th of a second. The flickering that occurs when shooting under a fluorescent light or mercury-vapor lamp is reduced.

SPORTS

(Variable Shutter Speed: 1/250 - 1/4000)

This setting allows fast-moving images to be captured one frame at a time, for vivid, stable slow-motion playback. The faster the shutter speed, the darker the picture becomes. Use the shutter function under good lighting conditions.

SNOW: Compensates for subjects that may otherwise appear too dark when shooting in extremely bright surroundings such as in the snow.

■ **SPOTLIGHT**: Compensates for subjects that may otherwise appear too bright when shooting under extremely strong direct lighting such as spotlights.

NOTE:

"SPOTLIGHT" has the same effect as -3 with the exposure control. (□ pg. 32)

** TWILIGHT: Makes evening scenes look more natural. White Balance (pg. 33) is automatically set to *** not be changed to your desired setting. When Twilight is chosen, the camcorder automatically adjusts the focus from approx. 10 m (32 ft) to infinity. From less than 10 m, adjust the focus manually.

SEPIA: Recorded scenes have a brownish tint like old photos. Combine this with the Cinema mode for a classic look.

B/W MONOTONE: Like classic black and white films, your footage is shot in B/W. Used together with the Cinema mode, it enhances the "classic film" effect.

CLASSIC FILM*: Gives recorded scenes a strobe effect.

STROBE*: Your recording looks like a series of consecutive snapshots.

 Available only when the VIDEO/MEMORY Switch is set to "VIDEO". (GR-D93/73 only)

Snapshot (For Video Recording)

This feature lets you record still images that look like photographs onto a tape.

1 Set the VIDEO/MEMORY Switch to "VIDEO". (GR-D93/73 only)

2 Set the Power Switch to "M" while pressing down the Lock Button located on the switch.

3 Open the LCD monitor fully. (pg. 12)

4 Set "SNAP MODE" to the desired mode. (c) pg. 25, 26)

5 Press **SNAPSHOT**.

- There is the sound effect of a shutter closing.
- The "PH0T0" indication appears and a still image will be recorded for approx. 6 seconds, then the camcorder reenters the Record-Standby mode.
- You can perform Snapshot also during recording. A still image will be recorded for approx. 6 seconds, then the normal recording resumes.
- Regardless of the Power Switch position ("A" or "M"), Snapshot recording takes place using the selected Snapshot mode.

NOTES:

• To remove the shutter sound, refer to "BEEP" on page 27.

- When "WIDE MODE" is set to "SQUEEZE \(\overline{\ove
- If Program AE with special effects (LIF) pg. 30) is engaged, certain modes of Program AE with special effects are disabled during Snapshot recording. In such a case, the icon blinks.
- If SNAPSHOT is pressed when "DIS" is set to "ON" (pg. 26), the Stabilizer will be disabled.
- During playback as well, all snapshot modes are available when " → M COPY" is set to "OFF" in VIDEO Menu.
 pg. 28) However, the shutter sound is not heard.
- During Snapshot recording, the image displayed in the viewfinder may be partially missing. However, there is no effect in the recorded image.
- When a cable is connected to the AV connector, the shutter sound is not heard from the speaker, however it is recorded onto the tape.

Motor Drive Mode


Keeping **SNAPSHOT** pressed in step **5** provides an effect similar to serial photography. (Interval between still images: approx. 1 second)

• The Motor Drive mode is disabled when "REC SELECT" is set to "

To pi. 1. (□ pg. 28)

Auto Focus

The camcorder's Full Range AF system offers continuous shooting ability from close-up (as close as approx. 5 cm (2") to the subject) to infinity.






Focus detection zone

- When two subjects overlap in the same scene.
- When illumination is low.*
- When the subject has no contrast (difference in brightness and darkness), such as a flat, one-color wall, or a clear, blue sky.*
- When a dark object is barely visible in the LCD monitor or the viewfinder.*
- When the scene contains minute patterns or identical patterns that are regularly repeated.
- When the scene is affected by sunbeams or light reflecting off the surface of a body of water.
- When shooting a scene with a high-contrast background.
- * The following low-contrast warnings appear blinking: 🛦,

∢, ▶ and ♣

- If the lens is smeared or blurred, accurate focusing is not possible. Keep the lens clean. (pp. 48) When condensation occurs, wipe with a soft cloth or wait for it to dry naturally.
- When shooting a subject close to the lens, zoom out first.
 pg. 12) If zoomed-in in the auto focus mode, the camcorder may automatically zoom out depending on the distance between the camcorder and the subject. This will not occur when "TELE MACRO" is set to "ON". (pg. 26)

MMENU/VOL.



Manual Focus

If you are using the viewfinder, you should already have performed "Viewfinder Adjustment" (pp. 9).

- Set the Power Switch to "M" while pressing down the Lock Button located on the switch.
- 2 Press FOCUS. The manual focus indicator appears.
- 3 To focus on a further subject. rotate the MMENU/VOL. Wheel towards "+". The "▶" indicator appears and blinks.

To focus on a nearer subject. rotate the MMENU/VOL. Wheel towards "-". The "◀" indicator appears and blinks.

To reset to Auto Focus Press FOCUS twice or set the Power Switch to "A".

If FOCUS is pressed once, the camcorder will enter the focus adjustment mode again.

While focusing on a nearer subject

Manual focus indicator

While focusing on a

further subject



Manual focus indicator

NOTES:

- Be sure to focus the lens in the maximum telephoto position when you use the Manual Focus mode. If you focus in on a subject in the wide-angle position, sharply focused images cannot be obtained when zoomed up because the depthof-field is reduced at longer focal lengths.
- When the focus level cannot be adjusted any further or closer, " ▲ " or " ♣ " will blink.

Exposure Control

Manual exposure control is recommended in the following situations:

- When shooting using reverse lighting or when the background is too bright.
- When shooting on a reflective natural background such as at the beach or when skiing.
- When the background is overly dark or the subject is bright.

- 1 Set the Power Switch to "M" while pressing down the Lock Button located on the switch.
- 2 Open the LCD monitor fully. (pg. 12)
- 3 Press the MMENU/VOL. Wheel in. The Menu Screen appears.
- 4 Rotate the MMENU/VOL. Wheel to select "[3] (EXPOSURE)", and press it.
- 5 Rotate the MMENU/VOL. Wheel to select "MANUAL", and press it.
- The exposure control indicator appears.
- **6** To brighten the image, rotate the **MMENU/VOL**. Wheel towards "+". To darken the image, rotate the MMENU/VOL. Wheel towards "-". (maximum ±6)
- +3 exposure has the same effect as the backlight compensation. (car pg. 33)
- -3 exposure has the same effect as when "" is set to "SPOTLIGHT". (cr pg. 31)
- 7 Press the MMENU/VOL. Wheel in. Exposure adjustment is complete.

To return to automatic exposure control Select "AUTO" in step 5. Or, set the Power Switch to "A".

NOTES:

- You cannot use the manual exposure control at the same time when "" is set to "SPOTLIGHT" or "SNOW" (pg. 30), or with the backlight compensation. (pg. 33)
- If the adjustment does not cause any visible change in brightness, set "GAIN UP" to "AUTO". (pg. 25, 26)

Iris Lock

Like the pupil of the human eye, the iris contracts in welllit environments to keep too much light from entering, and dilates in dim environments to allow in more light. Use this function in the following situations:

- · When shooting a moving subject.
- When the distance to the subject changes (so its size in the LCD monitor or the viewfinder changes), such as when the subject is backing away.
- When shooting on a reflective natural background such as at the beach or when skiing.
- When shooting objects under a spotlight.
- When zooming.

When the subject is close, keep the iris locked. Even when the subject moves away from you, the image will not darken or brighten.

Before doing the following, perform steps 1 - 5 in "Exposure Control" (pg. 32).

• Adjust zoom so that the subject fills the LCD monitor or the viewfinder, then press and hold the MMENU/VOL. Wheel for over 2 seconds. The exposure control indicator and the "L" indication appear.

7 Press the MMENU/VOL. Wheel in. The "II" indication changes to "L" and the iris is locked.

To return to automatic iris control

Rotate the MMENU/VOL. Wheel to select "AUTO", then press it in step 5. Or, set the Power Switch to



Iris Lock Indicator

• The exposure control indicator and "I " disappear.

To lock the exposure control and the iris

After step 5 of "Exposure Control", adjust the exposure by rotating the MMENU/VOL. Wheel. Then lock the iris in steps 6 and 7 of "Iris Lock". For automatic locking, rotate the MMENU/VOL. Wheel to select "AUTO", then press it in step 5. The exposure control and the iris become automatic.

Backlight Compensation

Backlight compensation brightens the subject quickly. Press BACKLIGHT. The indicator is displayed and the subject is brightened. If pressed again, 🐼 disappears and the brightness returns to the previous level.



- Using the BACKLIGHT Button may cause the light around the subject to become too bright and the subject to become white.
- Backlight compensations is also available when the Power Switch is set to "A".

White Balance Adjustment

The white balance that refers to the correctness of color reproduction under various lighting. If the white balance is correct, all other colors will be accurately reproduced. The white balance is usually adjusted automatically. However, more advanced camcorder operators control this function manually to achieve a more professional color/tint reproduction.

To change the setting

Set "

" to the desired mode. (

pg. 25)

• The selected mode indicator except "AUTO" appears.

[AUTO]: White balance is adjusted automatically.

MWB: Adjust the white balance manually when shooting under various types of lighting. (127 "Manual White Balance Adjustment")

- FINE: Outdoors on a sunny day.
- CLOUD: Outdoors on a cloudy day.
- HALOGEN: A video light or similar type of lighting is used.
- [] = Factory-preset

To return to automatic white balance

Set "■" to "AUTO". (pg. 25)

Or, set the Power Switch to "A".


NOTE:

White balance cannot be used when "" is set to "SEPIA" or "MONOTONE". (₽ pg. 31)

Manual White Balance Adjustment

Adjust the white balance manually when shooting under various types of lighting.

Set the Power Switch to "M" while pressing down the Lock Button located on the switch.




- **2** Open the LCD monitor fully. (🖙 pg. 12)
- **3** Set "**№**" to "MWB". (□ pg. 25)
- The

 indication blinks slowly.
- 4 Hold a sheet of plain white paper in front of the subject. Adjust zoom or position yourself so that the white paper fills the screen.
- 5 Press the MMENU/VOL. Wheel in until ☑ begins blinking rapidly.
- When the setting is completed. \(\sigma \) resumes normal blinking.
- **6** Press the MMENU/VOL. Wheel in twice. The Menu Screen closes and the Manual White Balance indicator is displayed.

- In step 4, it may be difficult to focus on the white paper. In such a case, adjust focus manually. (pp. 32)
- A subject can be shot under various types of lighting conditions indoors (natural, fluorescent, candlelight, etc.). Because the color temperature is different depending on the light source, the subject tint will differ depending on the white balance settings. Use this function for a more natural result.
- Once you adjust white balance manually, the setting is retained even if the power is turned off or the battery removed

Dubbing To Or From A VCR



- White to AUDIO L IN or OUT
- Red to AUDIO R IN or OUT
- Yellow to VIDEO IN or OUT
- ◆ To S-VIDEO IN or OUT*
- Connect when your TV/VCR has an S-VIDEO IN/OUT connector. In this case, it is not necessary to connect the yellow video cable.

To use this camcorder as a player

- **1** Following the illustrations, connect the camcorder and the VCR. Also refer to page 17.
- **2** Set the camcorder's **VIDEO/MEMORY** Switch to "VIDEO". (GR-D93/73 only)
- **3** Set the camcorder's Power Switch to "PLAY" while pressing down the Lock Button located on the switch.
- 4 Turn on the VCR's power.
- 5 Insert the source cassette in the camcorder.
- 6 Insert the recording cassette in the VCR.
- 7 Engage the VCR's AUX and Record-Pause modes.
- Refer to the instruction manual for the VCR.
- **8** Press ►/II on the camcorder to start playback of the source tape.
- **9** At the point you want to start dubbing, engage the VCR's Record mode.
- **10** To pause dubbing, engage the VCR's Record-Pause mode and press ►/II on the camcorder.
- 11 Repeat steps 8 10 for additional editing. Stop the VCR and camcorder.

NOTES:

- It is recommended to use the AC Adapter as the power supply instead of the battery pack. (
 pg. 7)
- As the camcorder starts to play your footage, it will appear on your TV. This will confirm the connections and the AUX channel for dubbing purposes.
- Before you start dubbing, make sure that the indications do not appear on the connected TV. If they do, they are being recorded onto the new tape.

To choose whether or not the following displays appear on the connected TV

- · Date/time
 - Set "DATE/TIME" to "AUTO", "ON" or "OFF". (IPP pg. 25, 28) Or, press **DISPLAY** on the remote control (provided with GR-D93/73 only) to turn on/off the date indication
- Time code Set "TIME CODE" to "OFF" or "ON". (pp g. 25, 28)
- Indications other than date/time and time code Set "ON SCREEN" to "OFF", "LCD" or "LCD/TV".
 (pq. 25, 28)


To use this camcorder as a recorder (GR-D93/73 only)

- 1) Perform steps 1 to 3 in "To use this camcorder as a player".
- 2) Set "S/AV INPUT" to "ON". (pg. 25, 28)
- 3) Set "REC MODE" to "SP" or "LP". (pg. 25, 26)
- 4) Insert the recording cassette in this camcorder.
- 5) Press the Recording Start/Stop Button to engage the Record-Pause mode. The " A/V.IN" indication appears on the screen.
- **6)** Press the Recording Start/Stop Button to start recording. The **♦** indication rotates.
- 7) Press the Recording Start/Stop Button again to stop recording. The \$\infty\$ indication stops rotating.

- After dubbing, set "S/AV INPUT" back to "OFF".
- Analog signals can be converted to digital signals with this procedure.
- It is also possible to dub from another camcorder.

Dubbing To Or From A Video Unit Equipped With A DV Connector (Digital Dubbing)

It is also possible to copy recorded scenes from the camcorder onto another video unit equipped with a DV connector. Since a digital signal is sent, there is little if any image or sound deterioration.



To use this camcorder as a player

- Make sure all units are turned off.
- **2** Connect this camcorder to a video unit equipped with a DV input connector using a DV cable as shown in the illustration.
- **3** Set this camcorder's **VIDEO/MEMORY** Switch to "VIDEO". (GR-D93/73 only)
- **4** Set this camcorder's Power Switch to "PLAY" while pressing down the Lock Button located on the switch.
- **5** Turn on the video unit's power.
- **6** Insert the source cassette in this camcorder.
- 7 Insert the recording cassette in the video unit.
- 8 Press ►/II on this camcorder to start playback of the source cassette.
- **9** At the point you want to start dubbing, engage the video unit's Record mode.
- **10** To pause dubbing, engage the video unit's Record-Pause mode and press ►/II on this camcorder.
- **1** Repeat steps **8 10** for additional editing. Stop the video unit and camcorder.

NOTES:


- It is recommended to use the AC Adapter as the power supply instead of the battery pack. (pp pg. 7)
- If the remote control is used when both the player and recorder are JVC video units, both units will perform the same operation. To prevent this from happening, press the buttons on both units. (GR-D93/73 only)
- If a blank portion or disturbed image is played back on the player during dubbing, the dubbing may stop so that an unusual image is not dubbed.
- Even though the DV cable is connected correctly, sometimes the image may not appear in step 9. If this occurs, turn off the power and make connections again.
- If "Playback Zoom" (pg. 16) or "Playback Special Effects" (pg. 16) is attempted (GR-D93/73 only) or SNAPSHOT is pressed during playback, only the original playback image recorded on the tape is output from the DV IN/OUT connector.
- When using a DV cable, be sure to use the optional JVC VC-VDV204U DV cable.

To use this camcorder as a recorder

- 1) Perform steps 1 to 4 in "To use this camcorder as a player".
- 2) Set "REC MODE" to "SP" or "LP". (pg. 25, 26)
- 3) Insert the recording cassette in this camcorder.
- **4)** Press the Recording Start/Stop Button to engage the Record-Pause mode.
- The " DV. IN " indication appears on the screen.
- 5) Press the Recording Start/Stop Button to start recording. The ♣ indication rotates.
- **6)** Press the Recording Start/Stop Button again to stop recording. The **♦** indication stops rotating.

- If no image is displayed on the LCD monitor, set "S/AV INPUT" to "OFF". (
 pg. 25, 28) (GR-D93/73 only)
- Digital Dubbing is performed in the sound mode recorded on the original tape, regardless of the current "SOUND MODE" setting. (LPP pg. 26)

Connection To A Personal Computer



[A] Using USB cable (GR-D93/73 only)

It is possible to do the following things:

- Transfer still images stored on a memory card to a PC.
- Transfer still/moving images recorded on a tape to a PC.
- Capture still/moving images in real-time.
- Use this camcorder as a WebCam.

[B] Using DV cable

It is also possible to transfer still/moving images to a PC with a DV connector by using the provided software, software equipped with the PC or commercially available software.

NOTES:

- Refer to "SOFTWARE INSTALLATION AND USB/DV CONNECTION GUIDE" for the installation of the bundled software and drivers.
- The software operation manual is provided as PDF file on the CD-ROM.
- It is recommended to use the AC Adapter as the power supply instead of the battery pack. (
 pg. 7)
- Never connect the USB cable and the DV cable simultaneously to the camcorder. Connect only the cable you wish to use to the camcorder. (GR-D93/73 only)
- When using a DV cable, be sure to use the optional JVC VC-VDV206U or VC-VDV204U DV cable depending on the type of DV connector (4 or 6 pins) on the PC.
- If the PC connected to the camcorder via the USB cable is not powered, the camcorder does not enter the USB mode. (GR-D93/73 only)
- The date/time information cannot be captured into the PC.
- Refer to the instruction manuals of the PC and Software.
- The still images can also be transferred to a PC with a DV connector-equipped capture board. (GR-D93/73 only)
- The system may not work properly depending on the PC or capture board you are using.

For GR-D93/73 owners:


"USB MODE" and/or "ACCESSING FILES" appears on the LCD monitor while the PC is accessing data in the camcorder or the camcorder is transferring a file to the PC.

NEVER disconnect the USB cable while "ACCESSING FILES" is displayed on the LCD monitor since this can result in product damage.

Audio Dubbing (GR-D93/73 only)

The audio track can be customized only when recorded in the 12-bit and SP modes. (Fig. pg. 26)

• Use the provided remote control.



1 Play back the tape to locate the point where editing will start, then press PAUSE (II).

2 While holding A. DUB (♠) on the remote control, press PAUSE (II). The "II♠" and "MIC" indicators appear.

3 Press PLAY (►), then begin "narrating". Speak into the microphone.

To pause dubbing, press PAUSE (■).

4 To end Audio Dubbing, press **PAUSE** (**II**), then **STOP** (■).

To hear the dubbed sound during playback Set "NARRATION" to "ON" or "MIX". (☞ pg. 25, 28)

NOTES:

- Sound is not heard from the speaker during Audio Dubbing.
 When editing onto a tape that was recorded at 12-bit the
- When editing onto a tape that was recorded at 12-bit, the old and new soundtracks are recorded separately.
- If you dub onto a blank space on the tape, the sound may be disrupted. Make sure you only edit recorded areas.
- If feedback or howling occurs during TV playback, move the camcorder's microphone away from the TV, or turn down the TV's volume.
- If you change from 12-bit to 16-bit in mid-recording and then use the tape for Audio Dubbing, it is not effective from the point where 16-bit recording began.
- During Audio Dubbing, when the tape moves to scenes recorded in the LP mode, scenes recorded in 16-bit audio or a blank portion, Audio Dubbing stops.
- To perform Audio Dubbing while watching on the television, make connections. (pp pg. 17)
- To perform Audio Dubbing with a video unit connected to the camcorder's AV connector, first set "S/AV INPUT" to "ON" in VIDEO Menu. (pp. 25, 28)
 The "AUX" indication appears instead of "MIC".

Insert Editing (GR-D93/73 only)

You can record a new scene into a previously recorded tape, replacing a section of the original recording with minimal picture distortion at the in and outpoints. The original audio remains unchanged.

• Use the provided remote control.

NOTES:

- Before performing the following steps, make sure that "TIME CODE" is set to "ON". (Pp. pg. 25, 28)
- Insert Editing is not possible on a tape recorded in the LP mode or on a blank portion of a tape.
- To perform Insert Editing while watching in the television, make connections. (pp. 17)
- Play back the tape, locate the Edit-Out point and press PAUSE (II). Confirm the time code at this point. (pp. 13)
- **2** Press **REW** (◀◀) until the Edit-In point is located, then press **PAUSE** (▮).
- 3 Press and hold INSERT (c) on the remote control, then press PAUSE (II). The "IIC" indicator and the Time Code (min.:sec.) appear and the camcorder enters Insert-Pause mode.
- **4** Press **START/STOP** to begin editing.
- Confirm the insert at the time code you checked in step 1.
- To pause editing, press START/STOP. Press it again to resume editing.
- **5** To end Insert Editing, press **START/STOP**, then **STOP** (■).

NOTES:

- Program AE with special effects (pp. 30) can be used to spice up the scenes being edited during Insert Editing.
- During Insert Editing, the date and time information changes.
- If you perform Insert Editing onto a blank space on the tape, the audio and video may be disrupted. Make sure you only edit recorded areas.
- During Insert Editing, when the tape moves to scenes recorded in the LP mode or a blank portion, Insert Editing stops. (pg. 43)

Power (pg. 6)

- Perform charging where the temperature is between 10°C and 35°C (50°F and 95°F). 20°C to 25°C (68°F to 77°F) is the ideal temperature range for charging. If the environment is too cold, charging may be incomplete.
- Charging time is based on room temperature of 20°C (68°F).
- Charging times are for a fully discharged battery pack.
- Charging time varies according to the ambient temperature and the status of the battery pack.
- To avoid interference with reception, do not use the AC Adapter near a radio.
- Since the AC Adapter processes electricity internally, it becomes warm during use. Be sure to use it only in wellventilated areas.
- The following operation stops charging:
 - Set the Power Switch to "PLAY", "A" or "M".
 - · Disconnect the AC Adapter from the camcorder.
- Unplug the AC Adapter from the AC outlet.
 Detect the bettery from the comparder.
- · Detach the battery from the camcorder.
- Using the optional AA-V40U AC Power Adapter/Charger, you can charge the BN-V408U/V416U/V428U battery pack without the camcorder. However, it cannot be used as an AC Adapter.

Loading/Unloading A Cassette (pg. 10)

- It takes a few seconds for the cassette holder to open. Do not apply force.
- If you wait a few seconds and the cassette holder does not open, close the cassette holder cover and try again. If the cassette holder still does not open, turn the camcorder off then on again.
- If the tape does not load properly, open the cassette holder cover fully and remove the cassette. A few minutes later, insert it again.
- When the camcorder is suddenly moved from a cold place to a warm environment, wait a short time before opening the cassette holder cover.
- Closing the cassette holder cover before the cassette holder recedes may cause damage to the camcorder.
- Even when the camcorder is switched off, a cassette can be loaded or unloaded. After the cassette holder is closed with the camcorder switched off, however, it may not recede. It is recommended to turn the power on before loading or unloading.
- When resuming recording, once you open the cassette holder cover a blank portion will be recorded on the tape or a previously recorded scene will be erased (recorded over) regardless of whether the cassette holder came out or not. See "Recording From The Middle Of A Tape" (pg. pg. 13).

VIDEO RECORDING (pg. 11)

- When you use the LCD monitor outdoors in direct sunlight, the LCD monitor may be difficult to see. If this happens, use the viewfinder instead.
- The cassette holder cannot be opened unless a power supply is attached.
- There may be a delay after you open the cassette holder cover until the cassette holder opens. Do not use force.
- Once the cassette holder is closed, it recedes automatically. Wait until it recedes completely before closing the cassette holder cover.
- When the Recording Start/Stop button is pressed, it may take a few seconds before actual recording starts. The ""
 indicator starts rotating when the camcorder actually starts recording.
- The time required to calculate and display the remaining tape length, and the accuracy of the calculation, may vary according to the type of tape used.
- "TAPE END" appears when the tape reaches its end, and the power goes off automatically if left in this condition for 5 minutes. "TAPE END" also appears when a cassette at its end is loaded.

VIDEO PLAYBACK (pg. 14)

- Clean the video heads using an optional dry cleaning cassette when:
 - · No picture during playback.
- Blocks of noise appear during playback.

For details, 🖙 pg. 46.

- If Stop mode continues for 5 minutes when power is supplied from a battery, the camcorder shuts off automatically. To turn on again, set the Power Switch to "OFF", then to "PLAY".
- You can also view the playback picture on the LCD monitor with it flipped over and pushed against the camcorder body.
- LCD monitor/viewfinder indications:
 - When power is supplied from a battery: the "battery indicator is displayed. (Fig. 43)
 - When power is supplied from an AC outlet: the "
 battery indicator does not appear.
- When a cable is connected to the AV connector, the sound is not heard from the speaker.

D.S.C. RECORDING (GR-D93/D73 only) (pg. 18)

- Even if "DIS" is set to "ON" (pg. 26), the Stabilizer will be disabled.
- If Program AE with special effects (p. pg. 30) is engaged, certain modes of Program AE with special effects are disabled during Snapshot recording. In such a case, the icon blinks.
- If shooting is not performed for approx. 5 minutes when the Power Switch is set to "A" or "M" and power is supplied from the battery pack, the camcorder shuts off automatically to save power. To perform shooting again, push back and pull out the viewfinder again or close and reopen the LCD monitor.
- The Motor Drive mode (programmer grammer) is disabled when the VIDEO/MEMORY Switch is set to "MEMORY".
- When a cable is connected to the AV connector, the shutter sound is not heard from the speaker.
- Still images taken are compliant to DCF (Design rule for Camera File system). They do not have any compatibility with devices which are not compliant to DCF.

40 EN TROUBLESHOOTING

If the problem still exists after following the steps below, please consult your nearest JVC dealer.

The camcorder is a microcomputer-controlled device. External noise and interference (from a TV, a radio, etc.) might prevent it from functioning properly. In such cases, first disconnect its power supply unit (battery pack, AC Adapter, etc.) and wait a few minutes; and then re-connect it and proceed as usual from the beginning.

Power

No power is supplied.

- The power is not connected properly.
- → Connect the AC Adapter securely. (pg. 7)
- The battery is dead.
- → Replace the dead battery with a fully charged one. (□ pg. 6, 7)
- The LCD monitor is not open fully or the viewfinder is not pulled out when recording.
- →Open the LCD monitor fully or pull out the viewfinder.

The POWER/CHARGE lamp blinks in the Record-Standby mode.

- If the Record-Standby mode continues for 5 minutes, the camcorder's power shuts off automatically.
 - Then, the **POWER/CHARGE** lamp will blink to indicate for charging if the battery pack is attached to the camcorder and its power is supplied from the AC Adapter.
- → Push back and pull out the viewfinder again or close and re-open the LCD monitor to return to the Record-Standby mode.

Video and D.S.C. Recording

Recording cannot be performed.

- The Power Switch is set to "PLAY" or "OFF".
- → Set the Power Switch to "A" or "M". (cr pg. 11, 18)
- For Video Recording –
- The tape's erase protection tab is set to "SAVE".
- → Set the tape's erase protection tab to "REC". (pg. 10)
- The VIDEO/MEMORY Switch is set to "MEMORY". (GR-D93/73 only)
- → Set the VIDEO/MEMORY Switch to "VIDEO".
- "TAPE END" appears.
- → Replace with new cassette. (

 pg. 10)
- The cassette holder cover is open.
- → Close the cassette holder cover.
- For D.S.C. Recording (GR-D93/73 only) —
- The VIDEO/MEMORY Switch is set to "VIDEO".
- → Set the VIDEO/MEMORY Switch to "MEMORY".

When shooting a subject illuminated by bright light, vertical lines appear.

 This is a result of exceedingly high contrast, and is not a malfunction.

When the screen is under direct sunlight during shooting, the screen becomes red or black for an instant.

• This is not a malfunction.

During recording, the date/ time does not appear.

- "DATE/TIME" is set to "OFF".
- → Set "DATE/TIME" to "ON". (மு pg. 25, 27)

During recording, sound cannot be heard.

• This is normal.

The LCD monitor or viewfinder indications blink.

- Certain Wipe/Fader effects, certain modes of Program AE with special effects, "DIS" and other functions that cannot be used together are selected at the same time.
- → Re-read the sections covering Wipe/Fader effects, Program AE with special effects and "DIS". (□ pg. 25 – 31)

Digital Zoom does not work.

- 16X (10X for GR-D93) optical zoom is selected.
- → Set "ZOOM" to "40X" or "700X". (127 pg. 26)
- The VIDEO/MEMORY Switch is set to "MEMORY". (GR-D93/73 only)
- → Set the VIDEO/MEMORY Switch to "VIDEO".

Colored bright spots appear all over the LCD monitor.

 White spots or bright spots of light (red, green or blue) may appear on the LCD monitor. This may occur when the Night-Alive function is activated during recording and is not a malfunction.

Video and D.S.C. Playback

Play, Rewind and Fast-Forward functions do not work.

- The Power Switch is set to "A" or "M".
- → Set the Power Switch to "PLAY". (pg. 14)
- VIDEO/MEMORY Switch is set to "MEMORY". (GR-D93/ 73 only)
- → Set the VIDEO/MEMORY Switch to "VIDEO".

The tape is moving, but there is no picture.

- Your TV has AV input terminals, but is not set to its VIDEO mode
- → Set the TV to the mode or channel appropriate for video playback. (
 pg. 17)
- The cassette holder cover is open.
- →Close the cassette holder cover. (pr pg. 10)

Blocks of noise appear during playback, or there is no playback picture and the screen becomes blue.

→ Clean the video heads with an optional cleaning cassette. (□ pg. 46)

A memory card cannot be played back.

- (GR-D93/73 only) —
- The Power Switch is set to "A" or "M".
- → Set the Power Switch to "PLAY". (□ pg. 20)

 The VIDEO/MEMORY Switch is set to "VIDEO".
- → Set the VIDEO/MEMORY Switch to "MEMORY".

Advanced features

The focus does not adjust automatically.

- · Focus is set to the Manual mode.
- → Set Focus to the Auto mode. (pg. 31)
- The lens is dirty or covered with condensation.
- →Clean the lens and check the focus again. (pg. 48)
- The recording was done in a dark place, or the contrast was low.

Snapshot mode cannot be used.

- The Squeeze mode (SQUEEZE) is selected.
- → Disengage the Squeeze (SQUEEZE) mode. (pg. 25, 26)

The color of Snapshot looks strange.

- The light source or the subject does not include white. Or there are various different light sources behind the subject.
- → Find a white subject and compose your shot so that it also appears in the frame. (pg. 18, 31)
- The Sepia (SEPIA) or Monotone (MONOTONE) mode is activated.
- → Disengage the Sepia (SEPIA) and Monotone (MONOTONE). (pg. 25, 31)

The image taken using Snapshot is too dark.

- Shooting was performed under backlit conditions.
- → Press BACKLIGHT. (pg. 33)

The image taken using Snapshot is too bright.

- The subject is too bright.
- → Set "E" to "SPOTLIGHT". (cr pg. 31)

White Balance cannot be activated.

- The Sepia (SEPIA) or Monotone (MONOTONE) mode is activated.
- → Disengage the Sepia (SEPIA) or Monotone (MONOTONE) mode before setting White Balance. (pg. 31)

Wipe/Fader effects do not work.

- The Power Switch is set to "A".
- → Set the Power Switch to "M". (pg. 8)

The Black & White Fader does not work.

- The Sepia (SEPIA) or Monotone (MONOTONE) mode is activated
- → Disengage the Sepia (SEPIA) and Monotone (MONOTONE). (pg. 25, 31)

Program AE with special effects does not work.

- The Power Switch is set to "A".
- → Set the Power Switch to "M". (pg. 8)

The image looks like the shutter speed is too slow.

- When shooting in the dark, the unit becomes highly sensitive to light when "GAIN UP" is set to "AUTO".
- → If you want the lighting to look more natural, set "GAIN UP" to "AGC" or "OFF". (pg. 25, 26)

Other problems

The POWER/CHARGE lamp on the camcorder does not light.

- The temperature of the battery is extremely high/low.
- · Charging is difficult in places subject to extremely high/low temperatures.
- → To protect the battery, it is recommended to charge it in places with a temperature of 10°C to 35°C (50°F to 95°F). (pg. 45)

SET DATE/TIME!" appears.

- The date/time is not set.
- → Set the date/time. (pg. 8)
- The built-in clock battery has run out and the previously set date/time has been erased.
- → Consult your nearest JVC dealer for replacement.

There is no picture.

- The camcorder is not getting power, or some other malfunction exists.
- → Turn the camcorder's power off and on again. (pg. 8)

Some functions are not available using the MMENU/VOL. Wheel.

- The Power Switch is set to "A".
- → Set the Power Switch to "M". (pg. 8)

Files stored in the memory card cannot be deleted.

- (GR-D93/73 only) —
- Files stored in the memory card are protected.
- → Remove protection from the files stored in the memory card and delete them. (pg. 22)

When the image is printed from the printer, a black bar appears at the bottom of the screen.

- This is not a malfunction.
- →By recording with "DIS" activated (pp. 25, 26) this can be avoided.

When the camcorder is connected via the DV connector, the camcorder does not operate.

- The DV cable was plugged/unplugged with power turned
- → Turn the camcorder's power off and on again, then operate it.

The rear of the LCD monitor is hot.

- The light used to illuminate the LCD monitor causes it to become hot.
- → Close the LCD monitor to turn it off or set the Power Switch to "OFF", and let the unit cool down.

Images on the LCD monitor appear dark or whitish.

- In places subject to low temperature, images become dark due to the characteristics of the LCD monitor. When this happens, the displayed colors differ from those that are actually recorded. This is not a defect of the camcorder.
- → Adjust the brightness and angle of the LCD monitor. (
 (□ pg. 9, 12)
- When the LCD monitor's fluorescent light reaches the end of its service life, images on the LCD monitor become dark.
- → Consult your nearest JVC dealer.

Colored bright spots appear all over the LCD monitor or the viewfinder.

• The LCD monitor and the viewfinder are made with high-precision technology. However, black spots or bright spots of light (red, green or blue) may appear constantly on the LCD monitor or the viewfinder during recording or playback. These spots are not recorded on the tape. This is not due to any defect of the unit. (Effective dots: more than 99.99 %)

The indicators and the image color on the LCD monitor are not clear.

 This may occur when the surface or the edge of the LCD monitor is pressed.

The cassette will not load properly.

- The battery's charge is low.
- →Install a fully charged battery. (pg. 6, 7)

The memory card cannot be removed from the camcorder.

- (GR-D93/73 only) —
- → Push in the memory card a few more times. (pg. 10)

Picture does not appear on the LCD monitor.

- The viewfinder is pulled out and "PRIORITY" is set to "FINDER".
- → Push the viewfinder back in or set "PRIORITY" to "LCD". (LF pg. 12, 25, 27)
- The LCD monitor's brightness setting is too dark.
- → Adjust the brightness of the LCD monitor. (pg. 9)
- → If the monitor is tilted upward 180 degrees, open the monitor fully. (

 pg. 12)

Images on the LCD monitor are jittery.

- The speaker volume is too great.
- → Turn the speaker volume down. (pg. 14)

The LCD monitor, the viewfinder and the lens have become dirty (ex. fingerprints).

→ Wipe them gently with soft cloth. Wiping strongly can cause damage. (

pg. 48) To clean the viewfinder, please consult your nearest JVC dealer.

Time code does not appear.

- "TIME CODE" is set to "OFF".
- → Set "TIME CODE" to "ON". (pg. 25, 27, 28)

An error indication (E01, E02 or E06) appears.

- A malfunction of some kind has occured. In this case the camcorder's functions become unusable.
- → pg. 44.

An error indication (E03 or E04) appears.

- A malfunction of some kind has occured. In this case the camcorder's functions become unusable.
- → pg. 44.

The remote control does not work.

- (GR-D93/73 only) —
- "REMOTE" is set to "OFF".
- → Set "REMOTE" to "ON". (127 pg. 25. 27)
- The remote control does not point at the remote sensor.
- → Point at the remote sensor. (pg. 15)
- The remote control batteries are exhausted.
- → Replace the batteries with fresh ones. (pp. 15)

Warning Indications

Displays the battery remaining power.

Remaining power level

(BB) -→ [| | | High Exhausted

As the battery power comes close to nil, the battery indicator blinks.

When the battery power is exhausted, power turns off automatically.

6

Appears when no tape is loaded. (pg. 10)

CHECK TAPE'S ERASE PROTECTION TAB

Appears when the erase protection tab is set to "SAVE" while the Power Switch is set to "A" or "M" and the VIDEO/MEMORY Switch (GR-D93/73 only) is set to "VIDEO". (F pg. 8)

W USE CLEANING CASSETTE

Appears if dirt is detected on the heads during recording. Use an optional cleaning cassette. (pg. 46)

■ CONDENSATION. OPERATION PAUSED

PLEASE WAIT

Appears if condensation occurs. (The two indications above swiches alternately every 3 seconds.) When this indication is displayed, wait more than 1 hour until condensation disappears.

TAPE!

Appears if a tape is not loaded when the Recording Start/ Stop Button or **SNAPSHOT** Button is pressed while the Power Switch is set to "A" or "M" and the VIDEO/ MEMORY Switch (GR-D93/73 only) is set to "VIDEO".

TAPE END

Appears when the tape ends during recording or playback. (pg. 38)

SET DATE/TIME!

- Appears when the date/time is not set. (pg. 8)
- Appears when the built-in clock (lithium) battery is discharged and the previously set date/time is erased. (cr pg. 8)

LENS CAP

Appears for 5 seconds after power is turned on if the lens cap is attached.

A. DUB ERROR!

— (GR-D93/73 only) —

Appears if Audio Dubbing is attempted on a blank portion of a tape. (pg. 37)

A. DUB ERROR!

- <CANNOT DUB ON A LP RECORDED TAPE> <CANNOT DUB ON A 16bit RECORDING> <CHECK TAPE'S ERASE PROTECTION TAB>
- (GR-D93/73 onlv) —
- Appears if Audio Dubbing is attempted on a tape recorded in the LP mode. (pp pg. 37)
- Appears if Audio Dubbing is attempted on a tape recorded in 16-bit audio. (pg pg. 37)
- Appears if A. DUB (=) on the remote control is pressed when the erase protection tab is set to "SAVE". (pg. 37)

INSERT ERROR!

(GR-D93/73 only)

Appears if Insert Editing is attempted on a blank portion of a tape. (pg. 37)

INSERT ERROR!

<CANNOT EDIT ON A LP RECORDED TAPE> <CHECK TAPE'S ERASE PROTECTION TAB>

- (GR-D93/73 only) —
- Appears if Insert Editing is attempted on a tape recorded in the LP mode. (pg. 37)
- Appears if **INSERT** (**O**) on the remote control is pressed when the erase protection tab is set to "SAVE". (pg. 37)

MEMORY IS FULL

(GR-D93/73 only) —

Appears when the memory card's memory is full and shooting is not possible.

COPYING FAILED

- Appears if dubbing of copyguarded signals is attempted while this camcorder is being used as a recorder.
- Appears in the following cases when dubbing from a tape to a memory card (as digital stills) (GR-D93/73
 - · when no memory card is loaded.
 - · when the memory card's memory is full.
 - · when the memory card is not formatted.
 - · when a write-protected SD Memory Card is loaded. (car pg. 19)

MEMORY CARD!

(GR-D93/73 onlv) —

Appears if there is no memory card loaded when you attempt to record on a memory card or access data on a memory card.

PLEASE FORMAT

(GR-D93/73 only) —

Appears when there is a problem with a memory card and its memory is corrupt, or it has not been initialized. Initialize the memory card. (pp pg. 24)

NO IMAGES STORED

— (GR-D93/73 only) —

Appears if there are no image files stored in the memory card when you attempt memory card playback.

CARD ERROR!

— (GR-D93/73 only) —

Appears when the camcorder does not recognize the loaded memory card. Remove the memory card once and insert it again. Repeat these procedures until no indication appears. If the indication still appears, the memory card is corrupted.

UNSUPPORTED FILE!

— (GR-D93/73 only) —

Appears when playing back a file that is not compatible with DCF or a file with a size that is not compatible with this camcorder.

CHECK CARD'S WRITE PROTECTION SWITCH

— (GR-D93/73 only) —

Appears when you attempt to shoot digital still images when the write protection tab on the SD Memory Card is set to the "LOCK" position.

E01, E02 or E06 UNIT IN SAFEGUARD MODE REMOVE AND REATTACH BATTERY

The error indications (E01, E02 or E06) show what type of malfunction has occured. When an error indication appears, the camcorder turns off automatically. Remove the power supply (battery, etc.) and wait a few minutes for the indication to clear. When it does, you can resume using the camcorder. If the indication remains, consult your nearest JVC dealer.

E03 or E04 UNIT IN SAFEGUARD MODE EJECT AND REINSERT TAPE

The error indications (E03 or E04) show what type of malfunction has occured. When an error indication appears, the camcorder turns off automatically. Eject the cassette once and re-insert it, then check if the indication clears. When it does, you can resume using the camcorder. If the indication remains, consult your nearest JVC dealer.

When using the AC Adapter in areas other than the USA

The provided AC Adapter features automatic voltage selection in the AC range from 110 V to 240 V.

USING HOUSEHOLD AC PLUG ADAPTER


In case of connecting the unit's power cord to an AC wall outlet other than American National Standard C73 series type use an AC plug adapter, called a "Siemens Plug", as shown.

For this AC plug adapter, consult your nearest JVC dealer.



Battery Packs

The supplied battery pack is a lithium-ion battery. Before using the supplied battery pack or an optional battery pack, be sure to read the following cautions:



• To avoid hazards...

- ...do not burn.
- ... do not short-circuit the
 - terminals. When transporting, make sure the provided battery cap is attached to the battery. If the battery cap is misplaced, carry the battery in a plastic bag.
- ...do not modify or disassemble.
- ...**do not** expose the battery to temperatures exceeding 60°C (140°F), as this may cause the battery to overheat, explode or catch fire.
- ... use only specified chargers.

To prevent damage and prolong service life...

- ... do not subject to unnecessary shock.
- ... charge in an environment where temperatures are within the tolerances shown in the chart below. This is a chemical reaction type battery cooler temperatures impede chemical reaction, while warmer temperatures can prevent complete charging.
- ... store in a cool, dry place. Extended exposure to high temperatures will increase natural discharge and shorten service life.
- ...fully charge and then fully discharge the battery every 6 months when storing the battery pack over a long period time.
- ...remove from charger or powered unit when not in use, as some machines use current even when switched off.

NOTES:

 It is normal for the battery pack to be warm after charging, or after use.

Temperature Range Specifications

Charging: 10° C to 35° C (50° F to 95° F) Operation: 0° C to 40° C (32° F to 104° F) Storage: -20° C to 50° C (-4° F to 122° F)

The lower the temperature, the longer recharging takes.

Cassettes

To properly use and store your cassettes, be sure to read the following cautions:

During use...

- ... make sure the cassette bears the Mini DV mark.
- ...be aware that recording onto prerecorded tapes automatically erases the previously recorded video and audio signals.
- ...make sure the cassette is positioned properly when inserting.
- ...do not load and unload the cassette repeatedly without allowing the tape to run at all. This slackens the tape and can result in damage.
- ...do not open the front tape cover. This exposes the tape to fingerprints and dust.

Store cassettes...

- ... away from heaters or other heat sources.
- ... out of direct sunlight.
- ...where they won't be subject to unnecessary shock or vibration.
- ... where they won't be exposed to strong magnetic fields (such as those generated by motors, transformers or magnets).
- ... vertically, in their original cases.

Memory Cards (GR-D93/73 only)

To properly use and store your memory cards, be sure to read the following cautions:

During use...

- ...make sure the memory card bears the SD or MultiMediaCard mark.
- ... make sure the memory card is positioned properly when inserting.
- While the memory card is being accessed (during recording, playback, deletion, initialization, etc.)...
- ... never unload the memory card and never turn off the camcorder.

Store memory cards...

- ... away from heaters or other heat sources.
- ...out of direct sunlight.
- ...where they won't be subject to unnecessary shock or vibration.
- ... where they won't be exposed to strong magnetic fields (such as those generated by motors, transformers or magnets).

LCD Monitor

To prevent damage to the LCD monitor, DO NOT...

- ... push it strongly or apply any shocks.
- ... place the camcorder with the LCD monitor on the bottom.
- To prolong service life...
- ... avoid rubbing it with coarse cloth.

Be aware of the following phenomena for LCD monitor use. These are not malfunctions...

- ...While using the camcorder, the surface around the LCD monitor and/or the back of the LCD monitor may heat up.
- ...If you leave power on for a long time, the surface around the LCD monitor becomes hot.

Main Unit

For safety, DO NOT...

- ... open the camcorder's chassis.
- ...disassemble or modify the unit.
- ... short-circuit the terminals of the battery pack. Keep it away from metallic objects when not in use.
- ...allow inflammables, water or metallic objects to enter the
- ...remove the battery pack or disconnect the power supply while the power is on.
- ... leave the battery pack attached when the camcorder is not in use.

Avoid using the unit...

- ...in places subject to excessive humidity or dust.
- ...in places subject to soot or steam such as near a cooking stove.
- ...in places subject to excessive shock or vibration.
- ... near a television set.
- ...near appliances generating strong magnetic or electric fields (speakers, broadcasting antennas, etc.).
- ...in places subject to extremely high (over 40°C or 104°F) or extremely low (under 0°C or 32°F) temperatures.

DO NOT leave the unit...

- ...in places of over 50°C (122°F).
- ...in places where humidity is extremely low (below 35%) or extremely high (above 80%).
- ... in direct sunlight.
- ...in a closed car in summer.
- ... near a heater.

To protect the unit, DO NOT...

- ... allow it to become wet.
- ...drop the unit or strike it against hard objects.
- ...subject it to shock or excessive vibration during transportation.
- ... keep the lens directed at extremely bright objects for long periods.
- ... expose the lens and viewfinder's lens to direct sunlight.
- ... carry it by holding the LCD monitor or the viewfinder.
- ... swing it excessively when using the hand strap or the grip.
- ... swing the soft camera case excessively when the camcorder is inside it.

Dirty heads can cause the following problems:





- ... No picture during playback.
- ... Blocks of noise appear during playback.
- ... During recording, the Head Clog Warning indicator "

 appears.
- ... Recording cannot be performed properly.

In such cases, use an optional cleaning cassette. Insert it and play back. If the cassette is used more than once consecutively, damage to the video heads may result. After the camcorder plays back for about 20 seconds, it stops automatically. Also refer to the cleaning cassette's instructions.

If, after using the cleaning cassette, the problems still exist, consult your nearest JVC dealer.

Mechanical moving parts used to move the video heads and video tape tend to become dirty and worn out over time. In order to maintain a clear picture at all times, periodic checkups are recommended after using the unit for about 1,000 hours. For periodic check-ups please consult your nearest JVC dealer.

How To Handle A CD-ROM

- Take care not to soil or scratch the mirror surface (opposite to the printed surface). Do not write anything or put a sticker on either the front or back surface. If the CD-ROM gets dirty, gently wipe it with a soft cloth outward from the center hole.
- Do not use conventional disc cleaners or cleaning spray.
- Do not bend the CD-ROM or touch its mirror surface.
- Do not store your CD-ROM in a dusty, hot or humid environment. Keep it away from direct sunlight.

About moisture condensation

- You have observed that pouring a cold liquid into a glass will cause drops of water to form on the glass' outer surface. This same phenomenon occurs on the head drum of a camcorder when it is moved from a cool place to a warm place, after heating a cold room, under extremely humid conditions or in a place directly subjected to the cool air from an air conditioner.
- Moisture on the head drum can cause severe damage to the video tape, and can lead to internal damage to the camcorder itself

Serious malfunctioning

If malfunctioning occurs, stop using the unit immediately and consult your local JVC dealer.

The camcorder is a microcomputer-controlled device. External noise and interference (from a TV, a radio, etc.) might prevent it from functioning properly. In such cases, first disconnect its power supply unit (battery pack, AC Adapter, etc.) and wait a few minutes and then re-connect it and proceed as usual from the beginning.

Declaration of Conformity

Model Number : GR-D93U/D73U/D33U

Trade Name : JVC

Responsible party : JVC AMERICAS CORP. Address : 1700 Valley Road Wayne,

N. J. 07470 Telephone Number : 973-317–5000

This device complies with Part 15 of FCC Rules.

Operation is subject to the following two conditions: (1)

This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired

operation.

Change or modifications not approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no quarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver


Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/ TV technician for help.


This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

After Use

- Turn off the camcorder.
- 2 Slide and hold OPEN/EJECT in the direction of the arrow, then pull the cassette holder cover open until it locks. The cassette holder opens automatically. Remove the cassette
- 3 Press "PUSH HERE" to close the cassette holder.
- Once the cassette holder is closed, it recedes automatically. Wait until it recedes completely before closing the cassette holder cover.
- **4** Slide **BATT.RELEASE** ① and remove the battery pack ② ③.





Cleaning The Camcorder

- 1 To clean the exterior, wipe gently with a soft cloth. Put the cloth in diluted mild soap and wring it well to wipe off heavy dirt. Then wipe again with a dry cloth.
- **2** Press the Monitor Opening Button and open the LCD monitor. Wipe gently with a soft cloth. Be careful not to damage the monitor. Close the LCD monitor.
- **3** To clean the lens, blow it with a blower brush, then wipe gently with lens cleaning paper.

NOTES:

- Avoid using strong cleaning agents such as benzine or alcohol
- Cleaning should be done only after the battery pack has been removed or other power units have been disconnected.
- Mould may form if the lens is left dirty.
- When using a cleaner or chemically treated cloth refer to the cautions of each product.
- To clean the viewfinder, please consult your nearest JVC dealer.

Camcorder

For General

Power supply

DC 11.0 V (Using AC Adapter)

DC 7.2 V (Using battery pack)

Power consumption

Approx. 3.3 W (GR-D73/33), Approx. 3.5 W (GR-D93)

(LCD monitor off, viewfinder on)

Approx. 4.6 W (GR-D73/33), Approx. 4.8 W (GR-D93)

(LCD monitor on, viewfinder off)

Approx. 8.6 W (Maximum)

Dimensions (W x H x D)

71 mm x 91 mm x 118 mm

(2-13/16" x 3-5/8" x 4-11/16") (with the LCD monitor closed and the viewfinder pushed back in)

Weight

Approx. 500 g (1.1 lbs)

(without cassette and battery)

Approx. 590 a (1.3 lbs)

(incl. cassette and battery)

Operating temperature 0°C to 40°C (32°F to 104°F)

Operating humidity

35% to 80%

Storage temperature

-20°C to 50°C (-4°F to 122°F)

Pickup

1/6" CCD (GR-D73/33), 1/4" CCD (GR-D93)

Lens

F 1.6, f = 2.7 mm to 43.2 mm, 16:1 power zoom lens (GR-D73/33). F 1.8. f = 3.8 mm to 38.0 mm, 10:1 power zoom lens (GR-D93)

Filter diameter

ø30.5 mm

LCD monitor

2.37" diagonally measured, LCD panel/TFT active matrix system

Viewfinder

Electronic viewfinder with 0.24" color LCD

Speaker

Monaural

White LED Light

Effective distance: 1.5 m

For Digital Video Camera

Format

DV format (SD mode)

Signal format

NTSC standard

Recording/Playback format

Video: Digital component recording

Audio: PCM digital recording, 32 kHz 4-channel (12-bit).

48 kHz 2-channel (16-bit)

Cassette

Mini DV cassette

Tape speed

SP: 18.8 mm/s, LP: 12.5 mm/s

Maximum recording time (using 80 min. cassette)

SP: 80 min., LP: 120 min.

For Digital Still Camera (GR-D93/73 only)

Storage media

SD Memory Card/MultiMediaCard

Compression system

Still image: JPEG (compatible)

File size

Still image:

2 modes (1024 x 768 pixels/640 x 480 pixels) (GR-D73)

4 modes (1600 x 1200 pixels/1280 x 960 pixels/ 1024 x 768 pixels/640 x 480 pixels) (GR-D93)

Picture quality

2 modes (FINE/STANDARD)

Approximate number of storable images

r pg. 18

For Connectors

S

S-Video input (GR-D93/73 only):

Y: 0.8 V to 1.2 V (p-p), 75 Ω , analog

C: 0.2 V to 0.4 V (p-p), 75 Ω , analog

S-Video output:

Y: 1.0 V (p-p), 75 Ω, analog

C: 0.29 V (p-p), 75 Ω , analog

ΑV

Video input (GR-D93/73 only): 0.8 V to 1.2 V (p-p), 75 Ω

Video output: 1.0 V (p-p), 75 Ω, analog

Audio input (GR-D93/73 only): 300 mV (rms), 50 kΩ,

analog, stereo

Audio output: 300 mV (rms), 1 k Ω , analog, stereo

Input/output: 4-pin, IEEE 1394 compliant

USB (GR-D93/73 only)

5-pin

AC Adapter


Power requirement

AC 110 V to 240 V \sim , 50 Hz/60 Hz

Output

DC 11 V ____, 1 A

Specifications shown are for SP mode unless otherwise indicated. E & O.E. Design and specifications subject to change without notice.



Controls

- ① Menu Wheel [MMENU/VOL.] (pg. 25)
 Speaker Volume Control [MMENU/VOL.] (pg. 14)
- 2 Snapshot Button [SNAPSHOT] (pg. 18, 31)
- 3 Power Zoom Lever [T/W] (pg. 12)
- 4 Manual Focus Button [FOCUS] (F pg. 32) Blank Search Button [BLANK SRCH] (F pg. 14)
- 5 Diopter Adjustment Control (pg. 9)
- 6 Recording Start/Stop Button (pp. 11)
- 7 Power Switch [A, M, PLAY, OFF] (pg. 8)
- ® Lock Button (pg. 8)
- Rewind Button [◄◄] (□ pg. 14)
 Night Button [NIGHT] (□ pg. 29)
- ⊕ Play/Pause Button [►/II] (□ pg. 14)
- (Index Button [INDEX] (GR-D93/73 only) (F pg. 20)
- 4 VIDEO/MEMORY Switch (GR-D93/73 only) (F pg. 8)
- (Is Information Button [INFO] (GR-D93/73 only) (Is pg. 21)
- (pg. 6)
- ® White LED Light Switch [LIGHT] (pg. 29)
- Monitor Opening Button (Fig. pg. 12)
 For models without button, simply pull on bottom end of LCD monitor to open.

Connectors

- S-Video Input**/Output Connector [S-VIDEO] (pg. 17, 34)
- USB (Universal Serial Bus) Connector (GR-D93/73 only) (pp pg. 36)
- Digital Video Connector [DV IN/OUT] (i.Link*) (pg. 35, 36)
- Audio/Video Input**/Output Connector [AV] (F pg. 17, 34)
- ② DC Input Connector [DC] (□ pg. 6, 7)
 - * i.Link refers to the IEEE1394-1995 industry specification and extensions thereof. The logo is used for products compliant with the i.Link standard.
 - **GR-D93/73 only

Indicators

25 POWER/CHARGE Lamp (127 pg. 8, 11)


Other Parts

- 26 Shoulder Strap Eyelet (F pg. 5)
- 27 Battery Pack Mount (pp pg. 7)
- 28 Grip Strap (127 pg. 7)
- 29 LCD Monitor (12 pg. 12, 13)
- 30 Speaker (□ pg. 14)
- 31 Stud Hole (pg. 9)
- 32 Tripod Mounting Socket (F pg. 9)
- 3 Card Cover [MEMORY CARD] (GR-D93/73 only) (□ pg. 10)
- 34 Cassette Holder Cover (pg. 10)
- 35 Stereo Microphone (pg. 37)
- White LED Light (pg. 29)
- 37 Viewfinder (pg. 9)
- 38 Remote Sensor (pg. 15)
- 39 Camera Sensor

(Be careful not to cover this area, a sensor necessary for shooting is built-in here.)


LCD Monitor/Viewfinder Indications

During Video Recording Only



- ① Selected Wipe/Fader Effect Indicator (pg. 30)
- ② Tape Running Indicator (F pg. 11) (Rotates while tape is running.)
- 3 Selected Wide Mode Indicator (pg. 26)
- 4 Recording Speed Mode (SP/LP) (pg pg. 26)
- 5 Tape Remaining Time (F pg. 12)
- ⑥ REC: (Appears during recording.) (□ pg. 11) PAUSE: (Appears during Record-Standby mode.) (□ pg. 11)
- ⑦ Insert Editing/Insert Editing Pause Mode (GR-D93/73 only) (□ pg. 37)
- 8 Wind Cut Indicator (F pg. 27)
- Sound Mode Indicator (pg. 26)
 (Appears for approx. 5 seconds after turning on the camcorder.)
- 10 Time Code (127 pg. 27, 28)
- 1 Digital Image Stabilizer ("DIS") (pg. 26)

During D.S.C. Recording Only (GR-D93/73 only)




- ① Image Size: 1600 (1600 x 1200)*, 1280 (1280 x 960)*, 1024 (1024 x 768) or 640 (640 x 480) (17 pg. 28) *GR-D93 only
- ② Shooting Icon (pp. 18) (Appears and blinks during shooting.)
- ③ Card Icon (pg. 18)

P: Appears during shooting.

Blinks in white when a memory card is not loaded.

- ④ Picture Quality: (FINE) and (STANDARD) (in order of quality) (pg. 27)
- ⑤ Remaining Number Of Shot (IFF pg. 18) (Displays the approximate remaining number of shots that can be stored during D.S.C. recording. The number increases or decreases depending on the Picture Quality/Image Size, etc.)

During Both Video And D.S.C. Recording




- ① Operation Mode (pg. 8)
- ②
 Night-Alive Indicator (☞ pg. 29)

 (Appears when Night-Alive is engaged.)

 A: Gain Up Mode (☞ pg. 26)

 (Appears when "GAIN UP" is set to "AUTO" and the shutter speed is automatically adjusted.)
- 3 White LED Light Indicator (pg. 29)
- 4 White Balance Indicator (F pg. 33)
- ⑤ Backlight Compensation Indicator (□ pg. 33)
 ±: Exposure Adjustment Indicator (□ pg. 32)
- Selected Program AE With Special Effects Indicator (pg. 30)
- 7 Iris Lock Indicator (pg. 32)
- ® Approximate Zoom Ratio (pg. 12) (Appears during zooming.)
- 10 PHOTO: (Appears when taking Snapshot.) (F pg. 31)
- BRIGHT: Brightness Control Indicator (LCD monitor/ Viewfinder) (□ pg. 9)
 (The level indicator ® moves.)
- 12 Battery Indicator (pg. 43)
- [®] Date/Time (□ pg. 8)
- (4) Manual Focus Adjustment Indicator (127 pg. 32)

During Video Playback



- ① Sound Mode Indicator (F pg. 28)
- 2 Blank Search Indicator (pg. 14)
- 3 Tape Speed (pp. 26)
- ④ ▶ : Playback

>> : Fast-Forward/Shuttle Search

◄ : Rewind/Shuttle Search

II : Pause

■ : Forward Frame-By-Frame Playback/Slow-Motion

◀ II : Reverse Frame-By-Frame Playback/Slow-Motion

: Audio Dubbing (GR-D93/73 only)

■ : Audio Dubbing Pause (GR-D93/73 only) (Appear while a tape is running.)

- ⑤ Sound Input For Audio Dubbing (GR-D93/73 only) (☞ pg. 37)
- 6 Battery Indicator (F pg. 43)
- 7 Date/Time (pg. 27, 28)
- ® VOLUME +, −: Volume Level Indicator (Speaker)
 (□ pg. 14)


(The level indicator @ moves.)

BRIGHT: Brightness Control Indicator (LCD monitor/ Viewfinder) (pg. 9)

(The level indicator @ moves.)

9 Time Code (pg. 27, 28)

During D.S.C. Playback (GR-D93/73 only)



- 1 Operation Mode Indicator (pg. 21)
- 2 Folder/File Number (pg. 21)
- 3 Battery Indicator (pg. 43)
- Brightness Control Indicator (LCD monitor/Viewfinder)
 pg. 9)

(The level indicator @ moves.)

54 EN TERMS

A	J
AC Adapter6, 7	Journalistic Shooting13
Audio Dubbing37	L
Auto Focus31	_
Auto Playback Of Images20	Loading A Cassette
Auto Shut Off11, 39	Loading A Memory Card10
В	M
_	Manual Focus32
Backlight Compensation	Memory Card 10, 45
Battery Pack	Menu Screen
Blank search14	CAMERA26
Brightness Adjustment Of The Display (BRIGHT)9	CAMERA DISPLAY27
brightness Adjustment Of The Display (Distant)	D.S.C. Playback21 – 24
C	DSC
Changing The Menu Settings25	MANUAL
Charging The Battery Pack6	VIDEO
Cleaning The Camcorder48	VIDEO DISPLAY
Clock adjustment (CLOCK ADJ.)8	Motor Drive Mode3
Connections	MultiMediaCard10, 45
Charging6	N
Dubbing34, 35	
To A PC	Night-Alive
To A TV Or VCR17	P
D	Picture Quality (QUALITY)2
Date/Time	Playback sound (SOUND MODE, NARRATION) 28
Display (DATE/TIME)27, 28	Playback Special Effects16
Settings8	Playback Zoom10
DCF (Design rule for Camera File system)20, 39	Power Switch Position
Deleting Files (DELETE)	Priority Setting (PRIORITY)2
Demonstration Mode (DEMO MODE)27	Program AE With Special Effects (PROGRAM AE)
Digital Image Stabilization (DIS)	Classic Film (CLASSIC FILM)3
DPOF Setting (Digital Print Order Format)23	Monotone (MONOTONE)3
Dubbing	Sepia (SEPIA)
Dubbing from tape to memory card19	Shutter Speed (SHUTTER)
E	Snow (SNOW)
Erase Protection10	Spotlight (SPOTLIGHT)3
Exposure Control (EXPOSURE)32	Strobe (STROBE)
F	Twilight (TWILIGHT)3
-	Protecting Files (PROTECT)
Fade-In/Out	Provided Accessories
Fast-Forward The Tape	R
Frame-By-Frame Playback16	Recording media selection (REC SELECT)28
G	Recording Mode (REC MODE)26, 28
Gain Up (GAIN UP)26	Recording Time
Grip Adjustment7	Tape10
1	Record-Standby1
I Instant Oise (IMAGE OIZE)	Remaining Power Level4
Image Size (IMAGE SIZE)	Remote control setting (REMOTE)
Index Playback Of Files	Resetting Menu Settings (CAM RESET)2
Indications on the LCD Monitor/Viewfinder52	Resetting The File Name24
Initializing A Memory Card (FORMAT)24	Rewind The Tape14
Insert Editing	·
Iris32	

s

SD Memory CardSelf Recording	
Shuttle Search	
Slow-Motion Playback	
Snapshot	
Snapshot Mode (SNAP MODE)	
Sound Mode (SOUND MODE)	
Speaker Volume	
Specifications	
S-Video/AV input (S/AV INPUT)	
	20, 04, 00
Т	
Telephoto setting (TELE MACRO)	
Time Code (TIME CODE)	
Tripod Mounting	
U	
Unloading A Cassette	10
Unloading A Memory Card	10
V	
VIDEO/MEMORY Switch Position	8
Viewfinder Adjustment	
w	
White Balance (W.BALANCE)	33
White LED Light	
Wide Mode (WIDE MODE)	
Cinema (CINEMA)	26
Squeeze (SQUEEZE)	
Wipe In/Out	
Z	
Zooming (ZOOM)	12 26



GR-D93 GR-D73 GR-D33

